

Atlas Copco Instruction Manual

Instruction Manual
for Atlas Copco WEDA Dewatering Pump
English

WEDA 30 | **all options**
WEDA 40



RENTWAY

**Instruction Manual
for Atlas Copco WEDA Dewatering Pump**

**WEDA 30
WEDA 40**

Original

Printed matter N°
9822 1686 00-0

12/2013



ATLAS COPCO - PORTABLE ENERGY DIVISION
www.atlascopco.com

Warranty and Liability Limitation

Use only authorized parts.

Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

The manufacturer does not accept any liability for any damage arising from modifications, additions or conversions made without the manufacturer's approval in writing.

Neglecting maintenance or making changes to the setup of the machine can result in major hazards.

While every effort has been made to ensure that the information in this manual is correct, Atlas Copco does not assume responsibility for possible errors.

Copyright 2013, Atlas Copco Portable OEM Solutions
IRMER+ELZE KOMPRESSOREN GmbH, D-32547 Bad Oeynhausen, Germany.

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

Preface

Please read the following instructions carefully before starting to use your pump.

It is a solid, safe and reliable machine, built according to the latest technology. Follow the instructions in this booklet.

Always keep the manual available near the machine.

In all correspondence always mention the pump type and serial number, shown on the data plate.

The company reserves the right to make changes without prior notice.

Table of contents

1	Safety precautions	7	5	Operating instructions	13
1.1	Introduction	7	5.1	Transport	13
1.2	Pictograms and symbols	7	5.2	Starting	13
1.3	Safety during use and operation	7	5.3	Stopping	13
1.4	Authorised personnel	8	6	Maintenance	14
1.5	Dangers when not following safety instructions	8	6.1	Preventive maintenance schedule	14
1.6	Safety-conscious working method	8	6.2	External damage, loose parts	15
1.7	Personal safety	8	6.3	Motor insulation resistance	15
1.8	Safety during maintenance	8	6.4	Oil	15
1.9	Electrical safety	8	6.5	Impeller	15
1.10	Conversion and spare parts	8	6.6	Power cable	15
1.11	Unintended use	9	6.7	Cable entry	15
1.12	Data plate	9	7	Troubleshooting	16
2	General description	10	8	Technical details	17
2.1	Housing and wet end	10	8.1	Dimensions	18
2.2	Impeller	10	8.2	Motor data	18
2.3	Overload protection	10	8.3	Wiring diagram	19
3	Main parts	10	8.4	Flow characteristics	21
4	Options	11	9	Spare parts	23
4.1	Float switch	11	9.1	Ordering spare parts	23
4.2	Motor Protection plug	11	9.2	Oil specification	23
4.3	Zinc anodes	12	10	Warranty	24
4.4	Epoxy coating	12	11	Disposal	24
4.5	Low suction collar	12	11.1	General	24
4.6	Discharges	12	11.2	Disposal of materials	24
			11.3	Declaration of conformity	25

RENTWAY

Safety precautions



To be read attentively and acted accordingly before operating, performing maintenance or repairing the unit.

INTRODUCTION

The policy of Atlas Copco is to provide the users of their equipment with safe, reliable and efficient products. Factors taken into account are among others:

- the intended and predictable future use of the products, and the environments in which they are expected to operate,
- applicable rules, codes and regulations,
- the expected useful product life, assuming proper service and maintenance,
- providing the manual with up-to-date information.

Before handling any product, take time to read the relevant instruction manual. Besides giving detailed operating instructions, it also gives specific information about safety, preventive maintenance, etc.

Keep the manual always at the unit location, easy accessible to the operating personnel.

These safety precautions are general and some statements will therefore not always apply to a particular unit.

Only people that have the right skills should be allowed to operate, adjust, perform maintenance or repair on Atlas Copco equipment.

It is the responsibility of management to appoint staff with the appropriate training and skill for each category of job.

Take the necessary steps to keep unauthorized persons away from the unit and eliminate all possible sources of danger at the unit.

When handling, operating, overhauling and/or performing maintenance or repair on Atlas Copco equipment, the mechanics are expected to use safe engineering practices and to observe all relevant local safety requirements and ordinances.

All responsibility for any damage or injury resulting from neglecting these precautions or by non-observance of ordinary caution and due care required in handling, operating, maintenance or repair, also if not expressly mentioned in this instruction manual, is disclaimed by Atlas Copco.

The manufacturer does not accept any liability for any damage arising from the use of non-original parts and for modifications, additions or conversions made without the manufacturer's approval in writing.

If any statement in this manual does not comply with local legislation, the stricter of the two shall be applied.

Statements in these safety precautions should not be interpreted as suggestions, recommendations or inducements that it should be used in violation of any applicable laws or regulations.

PICTOGRAMS AND SYMBOLS

This manual contains safety instructions that, when not observed, can lead to dangerous situations.



These safety instructions are indicated with a general pictogram indicating danger.



Safety instructions related to possible dangers when not observing the electrical safety instructions are indicated with this pictogram. Violating these safety instructions may result in death through electrocution.



This pictogram indicates safety instructions that can lead to damage to the pump when not observed.

All labels on the pump must be kept legible. Damaged labels have to be replaced.

SAFETY DURING USE AND OPERATION

This manual contains basic safety instructions that have to be observed during installation, use and maintenance. This manual is to be read by all operators/users before installing and operating the pump. It must be kept available to all operators/users at the operating site. Apart from the instructions in this chapter also the safety instructions mentioned in others sections of this manual must be observed.

AUTHORISED PERSONNEL

Only people that have the right skills should be allowed to operate, adjust, perform maintenance or repair on Atlas Copco equipment.

It is the responsibility of management to appoint operators with the appropriate training and skill for each category of job.

Skill level 1: Operator

An operator is trained in all aspects of operating the unit with the push-buttons, and is trained to know the safety aspects.

Skill level 2: Mechanical technician

A mechanical technician is trained to operate the unit the same as the operator. In addition, the mechanical technician is also trained to perform maintenance and repair, as described in the instruction manual, and is allowed to change settings of the control and safety system. A mechanical technician does not work on live electrical components.

Skill level 3: Electrical technician

An electrical technician is trained and has the same qualifications as both the operator and the mechanical technician. In addition, the electrical technician may carry out electrical repairs within the various enclosures of the unit. This includes work on live electrical components.

Skill level 4: Specialist from the manufacturer

This is a skilled specialist sent by the manufacturer or its agent to perform complex repairs or modifications to the equipment.

In general it is recommended that not more than two people operate the unit, more operators could lead to unsafe operating conditions.

DANGERS WHEN NOT FOLLOWING SAFETY INSTRUCTIONS

Not observing the safety instructions may lead to personal injury, damage to the equipment and environmental hazards. Not observing the safety instructions will void any warranty claim.

SAFETY-CONSCIOUS WORKING METHOD

All safety instructions in this manual as well as national accident preventing regulations and company-internal regulations regarding labour, operation and safety have to be observed.

PERSONAL SAFETY

Stay alert, watch what you are doing and use common sense when operating a pump. Do not use pumps while tired or under influence of drugs, alcohol or medication. A moment of inattention while operating pumps can result in serious personal injury.

Dress properly. Do not wear loose clothing or jewellery. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewellery, or long hair can be caught in moving parts.

Use approved safety equipment. Always wear eye protection, protective shoes and gloves.

SAFETY DURING MAINTENANCE

The owner is responsible for adequate training of the personnel maintaining the pumps. In principle all maintenance has to be performed on a non-energised pump. Observe the procedures as mentioned in the manual.

ELECTRICAL SAFETY

Pumps must be plugged into an outlet that is properly installed and grounded in accordance with all codes and ordinances. Never remove the grounding prong or modify the plug in any way. Do not use any adaptor plugs. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded.

Do not abuse the power cable. Never use the power cable to carry the pumps or pull the plug from an outlet. Keep the power cable away from heat, oil, sharp edges or moving parts. Damaged power cables increase the risk of electric shock.

Use a network protected by a ground fault circuit interrupter.

CONVERSION AND SPARE PARTS

Conversions are only allowed after written consent of the manufacturer. Always use original spare parts. Unauthorised conversion and / or the use of non-original spare parts will void any warranty claims.

UNINTENDED USE

The reliability of the pump is only guaranteed when it is used according the specifications in this manual. The limits as indicated are not to be exceeded under any circumstances.


Do not use the pump to transport water for human consumption, for water well pumping or for installation in an explosive atmosphere.

Caustic, slightly inflammable and other explosive substances such as petrol, petroleum, diluted nitrogen, greases, oils, salt water and waste water from toilets as well as sludgy water that has a slower flow capacity than water, should not be transported using the pump.

The temperature of the transported fluids should not exceed 40°C.

The appliance is not suitable for use as a stationary installation (such as a lifting device, fountain pump).

DATA PLATE



Reference	Name
1	Serial number
2	Pump type
3	Protection class
4	Production year
5	Rated voltage
6	Motor insulation class
7	Rated rpm
8	Rated current
9	Max. flow capacity
10	Rotation direction
11	Start kick direction
12	Weight
13	Max. head
14	Rated power input
15	Frequency
16	Number of phases
17	Max. fluid temperature
18	Max. submersed depth
19	Approval mark (CE, UL, CSA, ...)

General description

WEDA dewatering pumps are electrical submersible pumps for dewatering applications in construction sites, industry, mining, tanks, pools etc. The range consists of several dewatering pumps, all designed for tough pumping in demanding applications. The compact design and light weight make the pumps very versatile and easy to install.

The design with outer jacket for cooling and motor protector keeps the pump running safely under various conditions. The double mechanical seal runs in an oil bath and assures a long life time.

Features:

- Dry running capability. Motor protector.
- Plug and pump. Built-in high torque capacitor (1ph).
- The double mechanical seal runs in an oil bath and assures a long life time.
- Impeller from high chrome steel minimizes maintenance.
- The bearings are greased for life with high temperature grease and anti-corrosion additive.

WEDA 30 and 40 are compact versatile dewatering pumps for various pumping needs. The high chrome steel impeller is designed to handle the water in construction sites, manholes and industrial pits etc. with very low risk of clogging.

HOUSING AND WET END

The housing is made of aluminium and parts of wet end are rubber lined.


IMPELLER

The WEDA 30 and 40 pumps are equipped with a high chrome steel impeller.

OVERLOAD PROTECTION

The pump is supplied with an automatically resetting thermal overload protection.


Main parts



Reference	Name
1	Cable
2	Plug
3	Coupling
4	Discharge
5	Grease nipple
6	Strainer
7	Handle
8	Float switch (option)
9	Holder for float switch
10	Data plate

Options


FLOAT SWITCH



Reference	Name
1	Float switch
2	Float switch holder

470W214842 - Float switch kit
(Float switch kit for local assembly afterwards).
Use the pump with a float switch if automatic starting and stopping is required.
The pump starts if the float switch reaches an angle of +55° and stops at an angle of -55°.
For continuous operation clip (put) the float switch vertically in de float switch clamp.

MOTOR PROTECTION PLUG




Reference	Name
1	Over current relay
2	On/Off switch
3	Indicator lamp for phase control
4	Plug with phase inverter

470W157811 - Motor protection plug
(Only for pumps with 400V - 3ph motor).

To protect the motor against over current it is strongly recommended to use an external motor protector (option only for pumps with 400V - 3ph motor). The external motor protector can be ordered separately. It combines the on/off switch and the overload protection in one device, thus creating optimal operating comfort and protection for the pump.
If the indicator lamp 3 is lighting red, reverse two phases with a screw driver in plug 4.
After a fault the pump must be restarted manually pressing the switch on the external motor protector.

ZINC ANODES



Reference	Name
1	Zinc anode
2	Zinc anode

470W209289 - Zinc anode kit


When pumping salt water (which is highly aggressive towards aluminium), the pump should be protected with zinc anodes.

EPOXY COATING

8162171300 - Epoxy coating

For optimum protection when pumping salty water, water containing aggressive substances, or water with a high or low pH value the pump can be protected with an epoxy resin coating.

LOW SUCTION COLLAR



Reference	Name
1	Low suction collar

470W224848 - Low suction collar

The low suction collar allows you to pump residual water all the way down to 3 mm.

The low suction collar is made of rubber and is placed over the strainer.

If the low suction collar is placed 5 mm to the ground, the water can be pumped down to a residual amount of 3 mm.

DISCHARGES

Discharge	Part number
3" Hose standard with 1 clamp	470W203562
3" BSP - thread	470W203484
3" NPT - thread	470W203570
4" Hose standard with 1 clamp	470W203564
4" BSP - thread	470W203482
4" NPT - thread	470W203572
3" Cam lock adapter	8162164100
3" Cam lock coupling	8162164300
3" Storz coupling	470W157011
4" Storz coupling	470W157012

The pump can be equipped with several discharges, see table above.

Operating instructions

TRANSPORT



Always use the handle to lift the pump. Never use the power cable to lift or transport the pump. Always be careful not to let it fall or bump it against the wall or other equipment.

STARTING



The pump may not be used in an explosive / inflammable environment or used to pump inflammable liquids!



If the pump is being used for pumping water out of a swimming pool:


- nobody is allowed to be in the pool during pumping,
- the pump must be connected via a residual current device having a rated residual operating current not exceeding 30 mA.

Check the power cable with mains plug for damage before every use. If the power cable is damaged, exchange it immediately.

Check whether the power supply matches the rating on the **Data plate**.

Check whether the fluid to be pumped matches the characteristics mentioned in section **Technical details**.

The minimum start water level is approx. 35 mm.



Never operate the pump without the strainer.

Attach a suitable hose to the outlet and make sure it is thoroughly tightened. Avoid making excessive bends in delivery hoses or piping, as this may cause reduced flow. Turn discharge in horizontal (1) or vertical (2) direction according to application.

Run the electric cable so that sharp bends are avoided and there is no danger of the cable being pinched or otherwise being damaged.

Take care that the pump is submerged before putting the plug in the socket. Never install the pump directly on a weak soil layer or muddy ground. The pump may sink and mud/soil may enter the pump and reduce the flow. Check that the pump is pumping.

In case the motor stops due to overload or a blocked impeller, first pull the plug out of the socket before removing the pump from the pump site to check for why the pump has stopped. Remove the blockage, let the pump cool down and resume pumping.

STOPPING

Take the plug out of the socket and take the pump out of the pump site. If the pump has been operating in dirty water, allow it to run in clean water for a short period or flush clean water through the discharge port. If clay, cement or other sticky dirt remain in the pump this may clog the impeller and seal area.

Maintenance

PREVENTIVE MAINTENANCE SCHEDULE

Service task	Every month	Every 3 months	Every 6 months	Every 12 months in use	When worn
Grease check		x			
Pump lubrication			x		
Check wear parts		x			
Change wear parts					x
Adjustment of pump performance					
Replace sealing's of sealing package				x	x
Replace bearings of sealing package				x	x
Check contactor function					
Stator measurement			x		
Check cable	x				
Check cable gland	x				
Check pipes, valves	x				
Check float switch / Level sensor NVB function	x				
Check external damage, loose parts	x				

For maintenance kits and spare parts please refer to the Atlas Copco Spare parts list 9822 1666 00.

EXTERNAL DAMAGE, LOOSE PARTS


Make sure that all screws, bolts and nuts are tight. Check the condition of the pump lifting handle and replace if damaged or worn. Replace any external part that appears worn or damaged.

MOTOR INSULATION RESISTANCE

Use a 500 V DC Megger and measure the insulation between the phases and between any phase and ground. Resistance values should be over 1 M ohm. If abnormal readings are obtained, immediately hand the pump in for repair.

Also observe any local requirement regulations. The stricter one will prevail.

OIL



Reference	Name
1	Oil
2	Plug
3	Oil plug
4	O-ring

Check the condition of the oil to see if any water leakage has occurred. Remove the oil plug (3). Take an oil sample using a pipette. Check for impurities and emulsification. (Oil must be clear.) If water intrusion has occurred the seal must be replaced. Refill the seal chamber with fresh oil. Refer to section **Technical details** for type and quantity of oil.

IMPELLER

Inspect the impeller by removing the strainer and wear plate. Replace the impeller if it is damaged or severely worn.

POWER CABLE

Inspect the cable for cuts, scrapes or sharp bends. If the outer jacket is damaged, replace the cable. Do not make splices within wet wells.

CABLE ENTRY

Make sure that the cable entry flange and strain relief clamp are tight. If the cable entry is showing signs of leakage replace the cable.

Troubleshooting

Problem	Cause	Action
Pump will not run	1. Fuse blown or circuit breaker tripped 2. Broken cable 3. Power failure 4. Impeller jammed 5. Stator winding burnt-out 6. Float switch is defective or not correctly in position	1. Replace fuse or reset circuit breaker 2. Replace cable 3. Restore power supply 4. Clean impeller 5. Replace pump 6. Check float switch
Pump starts and stops	1. Strainer blocked 2. Insufficient water level 3. Voltage too low when using an extra cable 4. Water too hot	1. Clean strainer 2. Raise water level 3. Use a cable with larger section 4. Let the water cool down
Pump's capacity is too low	1. Delivery hose is squeezed 2. Total pumping head is too high 3. Strainer is blocked 4. Impeller is worn	1. Straighten delivery hose 2. Review pumping situation 3. Clean strainer 4. Replace impeller

Technical details


	Unit	WEDA 30	WEDA 40
Discharge, smooth and threaded BSP	inch	3"	3"
	inch	4"	4"
Weight	kg	20	25
Max solids handling	mm	7	7
Cable length	m	15	15
Max submersed depth	m	20	20
Impeller type		centrifugal impeller	centrifugal impeller
Impeller material		high chrome steel	high chrome steel
Shaft seals		mechanical seal	mechanical seal
Motor protection		thermal protection	thermal protection
Motor insulation class		F	F
pH range		5 - 8	5 - 8
Max fluid temperature	°C	40	40



The pump is designed to pump water that meets the specifications in the table above.

The pump is not to be used in explosive or inflammable environments or for pumping flammable liquids.

DIMENSIONS





Dimensions in mm	WEDA 30N	WEDA 30L	WEDA 40
H	476	503	503
D	220	220	220
W	286	286	286

MOTOR DATA

(50Hz)	Voltage	Max. power consumption kW	Max. current A
WEDA 30	230V/1ph	2.9	12.0
	230V/3ph	2.6	7.3
	400V/3ph	2.6	4.5
	500V/3ph	2.6	3.5
WEDA 40	230V/3ph	3.4	10.0
	400V/3ph	3.4	5.9
	500V/3ph	3.4	4.4


(60Hz)	Voltage	Max. power consumption kW	Max. current A
WEDA 30	230V/1ph	2.7	11.5
	230V/3ph	2.3	6.7
	460V/3ph	2.3	3.3
WEDA 40	230V/3ph	4.4	11.3
	460V/3ph	4.4	5.3

WIRING DIAGRAM




Reference	Name
1	Float switch (optional)

Colour code		
a = green/yellow	c = grey	e = blue
b = black	d = brown	



Reference	Name
1	Float switch (optional)


Optional Motor Protector




Reference	Name
1	Phase inverter
2	Overcurrent relay
3	In
4	On/Off switch
5	Phase control

Colour code	
a = green/yellow	c = grey
b = black	d = brown


FLOW CHARACTERISTICS




WEDA 30 - 50 Hz



WEDA 30 - 60 Hz



WEDA 40 - 50 Hz



WEDA 40 - 60 Hz

Spare parts

ORDERING SPARE PARTS

For spare parts see spare parts list:

9822 1666 00 - ASL WEDA 30

9822 1666 00 - ASL WEDA 40

OIL SPECIFICATION

Oil capacity: 0.25 L

Oil: partnr. 1605 2254 00 (2 L)

Oil: partnr. 1605 2255 00 (0.5 L)

To avoid errors in delivery, please give the following information when ordering spare parts:

1. Pump type
2. Pump serial number
3. Quantity required
4. Part number
5. Part description

Warranty

The warranty terms published by the relevant Atlas Copco Customer Center or authorized dealers are applicable in each country. We will repair potential failures of your pumps within the warranty period free of charge, provided that such failure is caused by faulty material or defects in manufacturing.

In the event of a warranty claim please contact your local dealer or the nearest authorized Atlas Copco Customer Service Center.

Disposal

GENERAL

When developing products and services, Atlas Copco tries to understand, address, and minimize the negative environmental effects that the products and services may have, when being manufactured, distributed, used and disposed.

Recycling and disposal policies are part of the development of all Atlas Copco products. Atlas Copco company standards determine strict requirements.

Material selection, substantial recyclability, disassembly possibilities and separability of materials and assemblies are considered, as well as environmental perils and dangers to health during the recycling and disposal of the unavoidable rates of non-recyclable materials.

Your Atlas Copco pump consists mostly of metallic materials, that can be remelted in steel and melting works and are therefore almost infinitely recyclable.

DISPOSAL OF MATERIALS

Dispose of contaminated substances and material separately, in accordance with locally applicable environmental legislation.

Before dismantling a machine at the end of its operating lifetime drain and dispose of all fluids of according the applicable local disposal regulations.

Separate the machine into metal, wiring, hoses, insulation and plastic parts.

Dispose of all components in accordance with applicable disposal regulations.

Remove spilled fluid mechanically; pick up the rest using an absorbing agent (for example sand, sawdust) and dispose of it in accordance with local disposal regulations. Do not drain into the sewage system or surface water.



This concept can only succeed with your help. Support us by disposing professionally. By assuring correct disposal of the product you help prevent possible negative consequences for environment and health as a result of inappropriate waste handling.

Recycling and re-usage of material help preserve natural resources.

DECLARATION OF CONFORMITY

Atlas Copco

EC DECLARATION OF CONFORMITY

1. Wa, IRMER+ELZE Kompressoren GmbH, declare under our sole responsibility, that the product
 2. Machine name: *portable submersible dewatering pump*
 3. Machine type: WEDA 40
 4. Serial number:

Which falls under the provisions of article 12.2 of the EC Directive 2006/42/EC on the approximation of the laws of the Member States relating to machinery, is in conformity with the relevant Essential Health and Safety Requirements of this directive.

The machinery complies also with the requirements of the following directives and their amendments as indicated.

Directive on the approximation of laws of the Member States relating to	Harmonized and/or Technical Standards used	Att mnt
1. Machinery safety	2006/42/EC EN ISO 12100:2011 EN ISO 809:2009	
2. Electromagnetic compatibility	2004/108/EC EN 60334-1:2010	
3. Low voltage equipment	2006/95/EC EN 60204-1:2011-01 EN ISO 60335-1:2012 EN ISO 60335-2-41:2010	

4. The harmonized and the technical standards used are identified above
 5. IRMER+ELZE Kompressoren GmbH is authorized to compile the technical file.

Conformity of the specification
to the directives

Conformity of the product to the specification
and by implication to the directives

Issued by

Engineering

Purchasing

Name

Signature

Date

Atlas Copco Portable OEM Solutions

IRMER+ELZE Kompressoren GmbH

Part of the Atlas Copco Group

Visitors address
 Mindener Strasse 29
 D-32547 Bad Oeynhausen
 Germany

Phone: +49 (0)5731 1801-0
 Fax: +49 (0)5731 1801-66
 Email: info@atlascopco.com

Gesch./Ref. nr.:
 Part. Leys
 Ust.-Nr. des DE: 154065482
 Amtsgericht Bad Oeynhausen
 HR B 2642

www.atlascopco.com

For info, please contact your local Atlas Copco representative

Form 88221/09/00
 04.01.2017 10:42:00

p.1(6)

Notes

RENTWAY



www.atlascopco.com