

Pioneering for You

wilo

Wilo-EMU KS



en Installation and operating instructions



RENTWAY

Table of contents

1	General information	5
1.1	About these instructions	5
1.2	Copyright	5
1.3	Subject to change	5
1.4	Warranty	5
2	Safety	5
2.1	Identification of safety instructions	5
2.2	Personnel qualifications	7
2.3	Electrical work	7
2.4	Monitoring devices	7
2.5	Use in fluids hazardous to health	8
2.6	Transport	8
2.7	Installing/dismantling	8
2.8	During operation	8
2.9	Maintenance tasks	9
2.10	Operating fluid	9
2.11	Operator responsibilities	9
3	Application/use	10
3.1	Intended use	10
3.2	Improper use	10
4	Product description	10
4.1	Design	10
4.2	Monitoring devices	11
4.3	Operating modes	12
4.4	Operation with frequency converter	12
4.5	Operation in an explosive atmosphere	12
4.6	Technical data	13
4.7	Type key	13
4.8	Scope of delivery	14
4.9	Accessories	14
5	Transportation and storage	14
5.1	Delivery	14
5.2	Transport	14
5.3	Storage	15
6	Installation and electrical connection	16
6.1	Personnel qualifications	16
6.2	Installation types	16
6.3	Operator responsibilities	16
6.4	Installation	16
6.5	Electrical connection	19
7	Commissioning	23
7.1	Personnel qualifications	23
7.2	Operator responsibilities	23
7.3	Direction of rotation check (for three-phase current motors only)	23
7.4	Operation in an explosive atmosphere	24
7.5	Before switching on	24
7.6	Switching on and off	25
7.7	During operation	25
8	Shut-down/dismantling	26
8.1	Personnel qualifications	26
8.2	Operator responsibilities	26
8.3	Shut-down	26
8.4	Removal	26

9 Maintenance and repair..... 27

9.1 Personnel qualifications..... 28

9.2 Operator responsibilities..... 28

9.3 Operating fluid 28

9.4 Maintenance intervals..... 29

9.5 Maintenance measures 29

10 Faults, causes and remedies 30

11 Spare parts..... 33

12 Disposal..... 33

12.1 Oils and lubricants..... 33

12.2 Protective clothing 33

12.3 Information on the collection of used electrical and electronic products..... 33

13 Appendix..... 34

13.1 Ex rating 34

RENTWAY

1 General information

1.1 About these instructions

These installation and operating instructions are an integral part of the product. Read these instructions before commencing work and keep them in an accessible place at all times. Strict adherence to these instructions is a requirement for intended use and correctly operating the product. All specifications and markings on the product must be observed.

The language of the original operating instructions is German. All other languages of these instructions are translations of the original operating instructions.

1.2 Copyright

These installation and operating instructions have been copyrighted by the manufacturer. The contents, of whatever type, may not be reproduced or distributed, or used for purposes of competition and shared with others.

1.3 Subject to change

The manufacturer reserves the right to make technical modifications to the product or individual components. The illustrations used may differ from the original and are intended as an example representation of the product.

1.4 Warranty

The specifications in the current "General Terms and Conditions" apply to the warranty and the warranty period. These can be found at www.wilo.com/legal

Any deviations must be contractually agreed and shall then be given priority.

Claim to warranty

If the following points are complied with, the manufacturer is obligated to rectify every qualitative or constructive flaw:

- The defects are reported in writing to the manufacturer within the warranty period.
- Application according to intended use.
- All monitoring devices are connected and tested before commissioning.

Exclusion of liability

Exclusion from liability excludes all liability for personal injury, material damage or financial losses. This exclusion ensues as soon as one of the following applies:

- Inadequate configuration due to inadequate or incorrect instructions by the operator or the client
- Non-compliance with installation and operating instructions
- Improper use
- Incorrect storage or transport
- Incorrect installation or dismantling
- Insufficient maintenance
- Unauthorised repairs
- Inadequate construction site
- Chemical, electrical or electro-chemical influences
- Wear

2 Safety

This chapter contains basic information which must be adhered to during the individual phases of the life cycle. Failure to follow the installation and operating instructions will result in injuries to persons, damage to the environment and the device and result in the loss of any claims for damages. Failure to follow the instructions can result in the following risks:

- Injury to persons from electrical, mechanical and bacteriological factors as well as electromagnetic fields
- Environmental damage from leakage of hazardous substances
- Property damage
- Failure of important functions of the product

Additionally, the instructions and safety instructions in the other chapters must be observed!

2.1 Identification of safety instructions

These installation and operating instructions set out safety instructions for preventing personal injury and damage to property. These safety instructions are shown differently:

- Safety instructions relating to personal injury start with a signal word, are **preceded by a corresponding symbol** and are shaded in grey.



DANGER

Type and source of the danger!

Consequences of the danger and instructions for avoidance.

- Safety instructions relating to property damage start with a signal word and are displayed **without** a symbol.

CAUTION

Type and source of the danger!

Consequences or information.

Signal words

→ DANGER!

Failure to observe the safety instructions will result in serious injuries or death!

→ WARNING!

Failure to follow the instructions can lead to (serious) injuries!

→ CAUTION!

Failure to follow the instructions can lead to property damage and a possible total loss.

→ NOTICE!

Useful information on handling the product

Symbols

These instructions use the following symbols:



Danger of electric voltage



Danger of bacterial infection



Danger of explosion



General warning symbols



Warning of crushing



Warning of cutting injuries



Warning of hot surfaces



Warning of high pressure



Warning of suspended loads



Personal protective equipment: Wear a safety helmet



Personal protective equipment: Wear foot protection



Personal protective equipment: Wear hand protection



Personal protective equipment: Wear mouth protection



Personal protective equipment: Wear safety goggles



Autonomous work prohibited! A second person must be present.



Useful information

Markups

- ✓ Prerequisite
- 1. Work step/list
 - ⇒ Notice/instructions
- Result

2.2 Personnel qualifications

Personnel must:

- Be instructed about locally applicable regulations governing accident prevention.
- Have read and understood the installation and operating instructions.

Personnel must have the following qualifications.

- Electrical work: A qualified electrician must carry out the electrical work.
- Installation/dismantling: The technician must be trained in the use of the necessary tools and fixation materials for the relevant construction site.
- Maintenance tasks: The technician must be familiar with the use of operating fluids and their disposal. In addition, the technician must have basic knowledge of mechanical engineering.

Definition of “qualified electrician”

A qualified electrician is a person with appropriate technical education, knowledge and experience who can identify **and** prevent electrical hazards.

2.3 Electrical work

- A qualified electrician must carry out the electrical work.
- When connecting to the mains, comply with the locally applicable laws and regulations of the local energy supply company.
- Before commencing work, disconnect the device from the mains and secure it against being switched on again without authorisation.
- Personnel are trained on the execution of the electrical connection and the options for switching off the device.
- Comply with the technical specifications contained in these installation and operating instructions and on the rating plate.
- Earth the device.
- Observe the manufacturer's specifications when connecting to electrical switching systems.
- Comply with the specifications on electro-magnetic compatibility when connecting electronic start-up controllers (e.g. soft starter or frequency converter). If required, take into account special measures (e.g. shielded cables, filters etc.).
- Replace defective power supply cables immediately. Contact customer service.

2.4 Monitoring devices

The following monitoring devices must be provided on-site:

Circuit breaker

The size of the circuit breakers conforms to the rated current of the pump. The switching characteristics should comply with group B or C. Observe local regulations.

Motor protection switch

Make provision for an on-site motor protection switch for devices without a plug! The minimum requirement is a thermal relay/motor protection switch with temperature compensation, differential triggering and anti-reactivation device in accordance with the local regulations. In case of sensitive mains, make provision for the installation on-site of other protective equipment (e.g. overvoltage, undervoltage or phase failure relay, etc.).

Residual-current device (RCD)

Comply with the regulations of the local energy supply company! The use of a residual-current device is recommended.

If persons come into contact with the device and conductive fluids, secure the connection **with** a residual-current device (RCD).

2.5 Use in fluids hazardous to health

There is a danger of bacterial infection when using the device in fluids hazardous to health! Thoroughly clean and disinfect the device after dismantling and prior to further use. The operator must ensure the following:

- The following protective equipment is provided and worn when cleaning the device:
 - Closed safety goggles
 - Breathing mask
 - Protective gloves
- All persons are informed about the fluid, the associated danger and its correct handling!

2.6 Transport

- The following protective equipment must be worn:
 - Safety shoes
 - Safety helmet (when using lifting equipment)
- Always hold the handle to transport the device. Never pull the power supply cable!
- Only use legally specified and approved lifting gear.
- Select the lifting gear based on the existing conditions (weather, attachment point, load, etc.).
- Always attach the lifting gear to the attachment points (handle or lifting eyelet).
- The stability of the lifting equipment must be ensured during operation.
- When using lifting equipment, a second person must be present to coordinate the procedure if required (e.g. if the operator's field of vision is blocked).
- Persons are not permitted to stand beneath suspended loads. Do **not** carry suspended loads over workplaces where people are present.

2.7 Installing/dismantling

- Wear the following protective equipment:
 - Safety shoes
 - Safety gloves for protection against cuts
 - Safety helmet (when using lifting equipment)
- Locally applicable laws and regulations for work safety and accident prevention must be complied with.
- Disconnect the device from the mains and secure it against being switched on again without authorisation.
- All rotating parts must be at a standstill.
- Provide adequate aeration in closed rooms.
- When working in chambers and closed spaces, a second person must be present for safety reasons.
- Take immediate countermeasures if there is a build-up of toxic or suffocating gases!
- Clean the device thoroughly. Disinfect devices that are used in fluids hazardous to health!
- Make sure that there is no risk of explosion when carrying out any type of welding work or work with electrical devices.

2.8 During operation

- Wear the following protective equipment:
 - Safety shoes
 - Ear protection (in accordance with the notice of the work regulations)
- Work area of the device is not a recreational area. No persons are allowed in the work area during operation.
- The operator must immediately report any faults or irregularities to their line manager.
- If safety-endangering defects occur, the operator must immediately deactivate the device:

- Malfunction of the safety and monitoring device
- Damage to the housing parts
- Damage to the electrical equipment
- Never reach into the suction port. The rotating parts can crush and sever limbs.
- If the motor emerges during operation, as well as in dry well installation, the motor housing can heat up to above 40 °C (104 °F).
- Open all gate valves in the piping on the suction and pressure side.
- Ensure minimum water submersion through dry-running protection.
- Under normal operating conditions, the sound pressure level of the device is below 85 dB(A). However, the actual sound-pressure level depends on several factors:
 - Installation depth
 - Installation
 - Fixation of accessories and pipe
 - Duty point
 - Immersion depth
- If the device is operated under normal operating conditions, the operator must measure the sound pressure. Ear protection must be worn for sound pressure levels of 85 dB(A) and above and this must be noted in the work regulations!

2.9 Maintenance tasks

- Wear the following protective equipment:
 - Closed safety goggles
 - Safety shoes
 - Safety gloves for protection against cuts
- Always carry out maintenance tasks outside the operating space/installation site.
- Only carry out maintenance tasks mentioned in these installation and operating instructions.
- Only original parts from the manufacturer may be used for maintenance and repairs. Use of parts other than the original parts releases the manufacturer from any liability.
- Collect any leakage of fluid and operating fluid immediately and dispose of it according to the locally applicable guidelines.
- Store tools at the designated locations.
- After completing work, reattach all safety and monitoring devices and check that they function properly.

Changing operating fluid

In case of a defect, a pressure **of several bar can build up** in the motor! This pressure escapes when the screw plugs are **opened**. If screw plugs are opened without due caution, they can be ejected at high speed! To avoid injuries, observe the following instructions:

- Adhere to the prescribed sequence of work steps.
- Unscrew the screw plugs slowly, but never unscrew them completely. As soon as the pressure escapes (audible whistling or hissing of air), stop turning the screw plug any further.

WARNING! Hot operating fluids can also spray out when the pressure is escaping. This can result in scalding! To avoid injuries, allow the motor to cool down to the ambient temperature before carrying out any work!

- When the pressure has completely dissipated, fully unscrew the screw plug.

2.10 Operating fluid

Motor in the motor compartment and the sealing chamber is filled with white oil or a water-glycol mixture. Operating fluids must be replaced during regular maintenance work and disposed of according to the local guidelines.

2.11 Operator responsibilities

- Installation and operating instructions must be in a language which the personnel can understand.
- Make sure that the personnel is relevantly trained for the specified work.
- Provide the necessary protective equipment and make sure that the personnel wears it.
- Safety and information signs mounted on the device must be always legible.
- Train the personnel pertaining to the functioning of the system.
- Eliminate risk from electrical current.
- Equip hazardous components inside the system with an on-site guard.
- Identify and cordon off the work area.
- To ensure safe working practice, define the responsibilities of the employees.

Children and persons younger than 16 years or with reduced physical, sensory or mental capacities or limited experience are prohibited from handling the product! A technician must supervise persons younger than 18 years!

3 Application/use

3.1 Intended use

Submersible pumps are suitable for pumping:
→ Wastewater
→ Fluids containing abrasive content (e.g. sand, gravel).

3.2 Improper use



DANGER
Explosion due to pumping of explosive fluids!

Pumping of highly flammable and explosive fluids (gasoline, kerosene, etc.) in pure form is strictly prohibited. There is a risk of fatal injury due to explosion! The pumps are not designed for these fluids.



DANGER
Danger due to fluids hazardous to health!

If the pump is used in fluids hazardous to health, decontaminate the pump after dismantling and before carrying out any other work! There is a risk of fatal injury! Observe the specifications in the work regulations! The operator must make sure that the personnel have received and read the work regulations!


The submersible pumps must **not be used** for pumping:
→ Drinking water
→ Sewage, with or without faeces
→ Fluids containing hard components (such as stones, wood, metal, etc.)
→ Fluids with dry matter

Intended use also includes compliance with this manual. Any other use is regarded as non-compliant with the intended use.

4 Product description

4.1 Design

Submersible drainage pump as a submersible monobloc unit for continuous duty in wet well installation.



1	Power supply cable
2	Handle/attachment point
3	Up to size 20: Motor housing
3	From size 24: Cooling jacket
4	Hydraulics housing
5	Suction port with suction strainer
6	Pressure port

Fig. 1: Overview EMU KS

4.1.1 Hydraulics

Centrifugal hydraulics with semi-open, multi-channel impeller and vertical threaded connection on the pressure side. A Storz coupling is fitted to the pressure connection. The hydraulics are **not** self-priming, in other words, the fluid must flow in either automatically or with supply pressure.

4.1.2 Motor

EMU KS...

For the single-phase current or three-phase current version, self-cooling submersible motors are used as the drive. Up to size 20, cooling is by means of an oil filling in the motor compartment and from size 24 by sheath current cooling. The waste heat is transferred directly to the fluid via the motor housing. The motor can be used in continuous duty both immersed and non-immersed. The connection cable is equipped with a shockproof plug for the single-phase current version and with a CEE plug for the three-phase current version. In single-phase current motors, the operating capacitor is integrated into the plug.

EMU KS... Ex

The system is driven by surface-cooled submersible motors in three-phase current version. The motor is cooled by the fluid around it. The waste heat is transferred directly to the fluid via the motor housing. The motor may emerge during operation. The connection cable is longitudinally sealed watertight and has bare cable ends or is equipped with a CEE plug.

4.1.3 Seal

The seal for the fluid and the motor compartment is made via two mechanical seals. The sealing chamber between the mechanical seals is filled with medical white oil.

4.1.4 Material

EMU KS...

- Pump housing: EN-GJL-250 (ASTM A48 Class 35/40B)
- Impeller: EN-GJL-250 (ASTM A48 Class 35/40B) or EN-GJS-500-7 (ASTM A536 70-50-05)
- Motor housing: G-AlSi12
- Cooling jacket (from size 24): G-AlSi12
- Seal on the motor side: C/Al₂O₃
- Seal on the fluid side: SiC/SiC
- Seal, static: FPM (FKM)

NOTICE! In the "GG" version, the motor housing is also made from EN-GJL-250 (ASTM A48 Class 35/40B).

EMU KS... Ex

- Pump housing: EN-GJL-250 (ASTM A48 Class 35/40B)
- Impeller: EN-GJL-250 (ASTM A48 Class 35/40B) or EN-GJS-500-7 (ASTM A536 70-50-05)
- Motor housing: EN-GJL-250 (ASTM A48 Class 35/40B)
- Seal on the motor side: SiC/SiC
- Seal on the fluid side: SiC/SiC
- Seal, static: FPM (FKM)

4.1.5 Fitted accessories

Float switch

In the "S" version and "DMS" version, the pump is equipped with a float switch. Depending on the fill level, it is possible to switch the pump on and off automatically, by using the float switch.

Plug

In the "E" version, a shockproof plug is attached and the "D" version has a CEE plug. The plug is designed for use in commercially available shock-proof or CEE sockets and is **not** overflow-proof.

4.2 Monitoring devices

Overview of monitoring devices:

	KS...	KS...Ex
Motor compartment	-	•
Motor winding	-	•
Motor bearings	-	-
Sealing chamber		

	KS...	KS...Ex
Internal electrode	–	–
External electrode	o	o

Key: – = not available/possible, o = optional, • = as standard

All the monitoring devices fitted must always be connected!

Monitoring of motor winding

The thermal motor monitoring protects the motor winding from overheating. Temperature limiter with bimetallic strip is fitted as standard.

Sealing chamber monitoring

The sealing chamber can be equipped with an external pencil electrode. The electrode registers fluid ingress through the mechanical seal on the fluid side. An alarm or deactivation of the pump can therefore take place through pump control.

4.3 Operating modes

Operating mode S1: Continuous duty

The pump can operate continuously at the rated load without exceeding the permissible temperature.

Operating mode: Non-immersed operation

The “non-immersed operation” operating mode describes the possibility of the motor emerging during the drainage pumping sequence. This allows a further lowering of the water level as far as the upper edge of the hydraulics. Observe the following points during non-immersed operation:

→ Operating mode

KS...: The motor can be run non-immersed in continuous duty (S1).

KS... Ex: The motor emerging in “non-immersed” operating mode is permissible.

DANGER! Risk of explosion due to motor overheating! The motor must not emerge in explosive atmospheres!

→ Max. fluid and ambient temperature: The max. ambient temperature corresponds to the max. fluid temperature shown on the rating plate.

“Slurping operation” operating mode

Slurping operation facilitates the pumping of very small amounts of fluid. This operating mode corresponds to a dry run. **DANGER! Risk of explosion due to motor overheating! Slurping operation is strictly forbidden in explosive atmospheres!**

4.4 Operation with frequency converter

Operation on the frequency converter is not permitted.

4.5 Operation in an explosive atmosphere

Type	Approval according to		
	ATEX	FM	CSA
KS 5 Ex	•	•	–
KS 6 Ex	•	•	–
KS 8	–	–	–
KS 9	–	–	–
KS 12	–	–	–
KS 14	–	–	–
KS 15	–	–	–
KS 16 Ex	•	•	–
KS 20	–	–	–
KS 24	–	–	–
KS 37	–	–	–
KS 70	–	–	–

Key: – = not available/possible, • = as standard

For use in explosive atmospheres, the pump must be marked as follows on the rating plate:

- “Ex” symbol of the corresponding approval
- Ex classification

For the relevant requirements, refer to the explosion protection chapter in the appendix of these installation and operating instructions!

ATEX approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to group II, category 2. The pumps can be used in both zone 1 and zone 2.

These pumps must not be used in zone 0!

FM approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to the protection class “Explosion proof, Class 1, Division 1”. Therefore, operation in areas with the required protection class “Explosion proof, Class 1, Division 2” is also possible.

4.6 Technical data

General	
Mains connection [U/f]	See rating plate
Rated power [P_2]	See rating plate
Max. delivery head [H]	See rating plate
Max. volume flow [Q]	See rating plate
Fluid temperature [t]	3...40 °C
Protection class	IP68
Insulation class [Cl.]	F
Max. switching frequency	15/h
Max. immersion depth [Σ]	12.5 m
Weight (net)	See rating plate
Explosion protection	
KS...	–
KS... Ex	ATEX, FM
Operating modes	
Immersed [OTs]	S1
Non-immersed [OTe]	
– KS...:	S1
– KS... Ex:	S2–15
Slurping operation	
– KS...:	S1
– KS... Ex:	–
Pressure connection	
KS 5 ... KS 9	Storz C (G 1¼)
KS 12 ... KS 16	Storz C (G 2)
KS 20	Storz B (G 2½)
KS 24	Storz B (G 3)
KS 37/KS 70	Storz A (G 4)

4.7 Type key

Example: Wilo-EMU KS 70ZN x¹ x² Ex

KS	Series
70	Size

Example: Wilo-EMU KS 70ZN x¹ x² Ex

Z	Pressure connection position without = lateral pressure connection Z = central pressure connection
N	Impeller version: without = standard impeller N = low-pressure impeller M = medium-pressure impeller H = high-pressure impeller
x ¹	Electric version: E = 1~ with shockproof plug E0 = 1~ bare cable end D = 3~ with CEE plug D0 = 3~ with bare cable end S = with float switch DMS = with float switch and CEE plug
x ²	Material version: without = standard version GG = cast iron version Ceram = with Ceram coating
Ex	Ex-rated

4.8 Scope of delivery

- Pump with 10 m (33 ft) or 20 m (66 ft) cable
- Storz coupling
- 90° bend
(for units with horizontal pressure connection)
- Connection cable with
 - Bare cable end
 - Plug
 - Float switch and plug
- Installation and operating instructions

4.9 Accessories

- Cable lengths up to 50 metres (164 ft)
- Pressure hoses
- Storz hose couplings

5 Transportation and storage
5.1 Delivery

After receiving the shipment, this must be checked immediately for defects (damage, completeness). Defects must be noted on the freight documentation! Furthermore, defects must be notified to the transport company or the manufacturer immediately on the day of receipt of shipment. Subsequently notified defects can no longer be asserted.

5.2 Transport**WARNING****Standing under suspended loads!**

Never allow anyone to stand under suspended loads! Danger of (serious) injuries caused by falling parts. Loads may not be carried over work places where people are present!

**WARNING****Head and foot injuries due to a lack of protective equipment!**

Danger of (serious) injuries during work. Wear the following protective equipment:

- Safety shoes
- Safety helmet must be worn if lifting equipment are used!

NOTICE**Only use lifting equipment in a technically sound condition!**

Only use lifting equipment in a technically sound condition for lifting, lowering and transporting the pump. Ensure that the pump does not become jammed during lifting and lowering. Do **not** exceed the max. permissible bearing capacity of the lifting equipment!

CAUTION**Soaked packaging may tear!**

The product may fall on the ground if unprotected and may be damaged. Lift wet packaging carefully and replace it immediately!

Only remove the outer packaging at the place of utilisation to ensure that the pump is not damaged during transport. Use tear-proof plastic sacks of sufficient size to package used pumps for transport in a leak-proof manner.

The following points must also be observed:

- Adhere to the applicable national safety regulations.
- Use legally specified and approved lifting gear.
- Select the lifting gear based on the existing conditions (weather, attachment point, load, etc.).
- Only attach the lifting gear to the attachment point. Fix with a shackle.
- Use lifting equipment with sufficient bearing capacity.
- The stability of the lifting equipment must be ensured during operation.
- When using lifting equipment, a second person must be present to coordinate the procedure if required (e.g. if the operator's field of vision is blocked).




Fig. 2: Attachment point

5.3 Storage

**WARNING****Sharp edges on the impeller and suction port!**

Sharp edges can form on the impeller and suction port. There is danger of limbs being severed! Protective gloves must be worn to protect from cuts.

CAUTION**Total damage due to moisture ingress**

Moisture ingress in the power supply cable damages the power supply cable and the pump! Never immerse the end of the power supply cable in a fluid and firmly seal it during storage.

Newly supplied pumps can be stored for one year. Contact customer service to store the pump for more than one year.

The following must be observed for storage:

- Place the pump upright (vertical) on a firm bearing surface and **secure it against slipping and falling over!**
- The max. storage temperature is -15°C to $+60^{\circ}\text{C}$ (5°F to 140°F) at a max. relative humidity of 90 %, non-condensing. Frost-proof storage at a temperature of 5°C to 25°C (41°F to 77°F) with relative humidity of 40 % to 50 % is recommended.
- Do not store the pump in rooms in which welding work is carried out. The resulting gases or radiation can corrode the elastomer parts and coatings.
- Seal the suction and pressure connection tightly.

- Protect power supply cables against kinking and damage.
- Protect the pump from direct sunlight and heat. Extreme heat can cause damage to the impellers and the coating!
- Impellers must be turned by 180 ° at regular intervals (3 – 6 months). This prevents locking of the bearings and renews the lubrication film of the mechanical seal.

WARNING! There is a risk of injury due to sharp edges on the impeller and suction port!

- Elastomer parts and the coating are subject to natural brittleness. Contact customer service if the pump must be stored for more than 6 months.

After storage, remove any dust and oil from the pump and check the coating for damage. Repair damaged coatings before further use.

6 Installation and electrical connection

6.1 Personnel qualifications

- Electrical work: A qualified electrician must carry out the electrical work.
- Installation/dismantling: The technician must be trained in the use of the necessary tools and fixation materials for the relevant construction site.

6.2 Installation types

- Vertical portable wet well installation

The following installation types are **not** permitted:

- Vertical stationary wet well installation with suspension unit
- Vertical stationary dry well installation
- Horizontal installation

6.3 Operator responsibilities

- Observe locally applicable accident prevention and safety regulations of trade associations.
- Observe all regulations for working with heavy loads and under suspended loads.
- Provide protective equipment and ensure that the protective equipment is worn by personnel.
- Observe local sewage technology regulations for the operation of sewage systems.
- Avoid pressure surges!
Pressure surges can occur in long pressure pipes with steep terrain. These pressure surges can lead to the destruction of the pump!
- Ensure the cooling time of the motor depending on the operating conditions and the size of the pump chamber.
- Structural components and foundations must be of sufficient stability in order to allow the device to be fixed securely and functionally. The operator is responsible for the provision and suitability of the structural component/foundation!
- Check that the available consulting documents (installation plans, design of the operating space, inflow conditions) are complete and correct.

6.4 Installation



DANGER

Risk of fatal injury due to dangerous lone working practices!

Work in chambers and narrow rooms as well as work involving risk of falling are dangerous work. Such work may not be carried out autonomously! A second person must be present for safety reasons.



WARNING

Hand and foot injuries due to lack of protective equipment!

Danger of (serious) injuries during work. Wear the following protective equipment:

- Safety gloves for protection against cuts
- Safety shoes
- Safety helmet must be worn if lifting equipment are used!

NOTICE**Only use lifting equipment in a technically sound condition!**

Only use lifting equipment in a technically sound condition for lifting, lowering and transporting the pump. Ensure that the pump does not become jammed during lifting and lowering. Do **not** exceed the max. permissible bearing capacity of the lifting equipment!

- Prepare operating space/installation location as follows:
 - Clean, free of coarse solids
 - Dry
 - Frost-free
 - Decontaminated
- Take immediate countermeasures if there is a build-up of toxic or suffocating gases!
- Use the handle for lifting, lowering and transporting the pump. Never carry or drag the pump by the power supply cable!
- It must be possible to attach lifting equipment safely. The storage place and the operating space/installation site must be accessible with the lifting equipment. The set-down location must have a solid bearing surface.
- Attach the lifting gear to the handle using a shackle. Only use lifting gear which has been technically approved.
- The routed power supply cables must allow safe operation. Check whether the cable cross-section and the cable length are sufficient for the selected installation type.
- The corresponding IP class must be observed when using switchgear. Install the switchgear in an overflow-proof position and away from potentially explosive areas!
- Avoid air intake into the fluid, use baffles or deflector plates for the inlet. Air which has entered the system can collect in the pipe system and lead to impermissible operating conditions. Air pockets must be removed via ventilation systems!

6.4.1 Maintenance tasks**6.4.1.1 Rotate impeller**

After a storage period of more than 6 months, turn the impeller prior to installation.

**WARNING****Sharp edges on the impeller and suction port!**

Sharp edges can form on the impeller and suction port. There is danger of limbs being severed! Protective gloves must be worn to protect from cuts.

- ✓ The pump is **not** connected to the mains!
- ✓ Protective equipment has been put on!
- 1. Place the pump upright on a firm surface.

WARNING! Risk of hands being crushed. Make sure that the pump cannot fall over or slip!

NOTICE! Do not position the pump horizontally, as otherwise oil can escape from the motor!
- 2. Pumps **without** suction strainer: Reach into the hydraulics housing carefully from below and slowly and turn the impeller.
 Pump with suction strainer: Insert a suitable tool through the suction strainer and turn the impeller.

6.4.2 Portable wet well installation**WARNING****Risk of burns from hot surfaces!**

Motor housing can become hot during operation. It may cause burns. Allow the pump to cool down at ambient temperature after switching it off!

**WARNING****Separation of pressure hose!**

Separation or movement of the pressure hose can lead to (serious) injuries. Securely attach the pressure hose to the outlet! Prevent buckling of the pressure hose.

For portable installation, the pump is equipped with a strainer. The strainer filters coarse solids out of the fluid and enables secure standing if placed on a solid load bearing surface. This allows the pump to be installed anywhere in the operating space/installation location. To prevent sinking in, a hard base must be used at the installation location in case of soft load bearing surfaces. A pressure hose or pipework is connected on the pressure side.

Work steps

1	Pressure hose
2	Storz coupling (pressure hose)
3	Storz coupling (pressure connection)
4	Suction strainer
5	Pump
6	Handle: Attachment point for lifting equipment
7	Connection cable
8	Slurping operation




Fig. 3: Wet well installation, portable

✓ Pressure connection prepared: Hose connection or Storz coupling fitted.

1. Use a shackle to attach the hoisting gear to the attachment point of the pump.
 2. Lift and align the pump at the installation location.
 3. Place the pump on a solid load bearing surface. **CAUTION! Prevent the pump sinking in!**
 4. Lay the pressure hose and fasten it to a certain point (e.g. drainage).
DANGER! Separation or movement of the pressure hose can lead to (serious) injuries! Secure the pressure hose at the outlet.
 5. Lay the connection cable properly. **CAUTION! Do not damage the connection cable!**
- The pump is installed, the qualified electrician can make the electrical connection.

6.4.3 Level control

With a level control device, the current fill levels are determined and the pump is switched on and off automatically depending on the fill levels. Fill levels are recorded by using different sensor types (float switches, pressure and ultrasound measurements or electrodes). The following must be observed when using a level control device:

- Float switches can move freely!
- The water level must **not fall below** the minimum permissible!
- The maximum switching frequency **must not be exceeded!**
- If the fill levels fluctuate strongly, a level control with two measuring points is recommended. This makes it possible to achieve larger differential gaps.

Use of attached float switch

The "S" version is equipped with a float switch. The pump is switched on and off depending on the fill level. The switching level is determined by the cable length of the float switch.

Use of on-site level controls

When using an on-site level control device, refer to the manufacturer's own installation and operating instructions for specifications on the installation.

6.5 Electrical connection



DANGER

Risk of death due to electrocution!

Improper conduct when carrying out electrical work can lead to death due to electric shock! Electrical work must be carried out by a qualified electrician in accordance with the locally applicable regulations.



DANGER

Risk of explosion due to incorrect connection!

- Always connect the pump to an electrical outlet outside the explosive area. If the connection must be made within the explosive area, then connection must be carried out in an Ex-rated housing (ignition protection class DIN EN 60079-0)! Non-observance may lead to fatal injury due to explosion!
- Connect the potential compensator to the earth terminal indicated. The earth terminal is installed in the area of the power supply cable. A cable cross-section in accordance with the locally applicable regulations must be used for the potential compensator.
- Connection must always be carried out by a qualified electrician.
- For the electrical connection, also note the additional information in the chapter on potentially explosive areas found in the appendix of these installation and operating instructions!

- The mains connection must match the specifications on the rating plate.
- Power supply on mains side for three-phase current motors with clockwise rotating field.
- Lay the power supply cables in accordance with the locally applicable regulations and connect them according to the wire assignment.
- Connect the monitoring devices and check their function.
- Earth the device properly in accordance with applicable local regulations.

6.5.1 Fuse on mains side

Circuit breaker

The size of the circuit breakers conforms to the rated current of the pump. The switching characteristics should comply with group B or C. Observe local regulations.

Motor protection switch

Make provision for an on-site motor protection switch for devices without a plug! The minimum requirement is a thermal relay/motor protection switch with temperature compensation, differential triggering and anti-reactivation device in accordance with the local regulations. In case of sensitive mains, make provision for the installation on-site of other protective equipment (e.g. overvoltage, undervoltage or phase failure relay, etc.).

Residual-current device (RCD)

Comply with the regulations of the local energy supply company! The use of a residual-current device is recommended.

If persons come into contact with the device and conductive fluids, secure the connection **with** a residual-current device (RCD).

6.5.2 Maintenance tasks

Carry out the following maintenance tasks prior to installation:

- Check the insulation resistance of the motor winding.
- KS...Ex only: Test the resistance of the temperature sensor.
- Test the resistor of the pencil electrode (optionally available).

If the measured values differ from the specifications, moisture may have penetrated into the motor or the power supply cable or the monitoring device is defective. Contact customer service in the event of a fault.

6.5.2.1 Checking the insulation resistance of the motor winding

Use an insulation tester to measure the insulation resistance (measuring voltage = 1000 V). Observe the following values:

6.5.2.2 Test the resistor of the temperature sensor

- At the time of initial commissioning: Insulation resistance may not be less than 20 MΩ.
- For further measurements: Value must be greater than 2 MΩ.

Measure the resistor of the temperature sensors with an ohmmeter. The following measured values must be complied with:

- **Bimetallic strip**: Measured value = 0 Ohm (passage).
- **PTC sensor** (PTC thermistor): Measured value depends on the number of sensors installed. At PTC sensor has a cold resistance of between 20 and 100 Ohm.
 - With **three** sensors in series, the measured value is between 60 und 300 Ohm.
 - With **four** sensors in series, the measured value is between 80 und 400 Ohm.

6.5.2.3 Testing the resistor of the external electrode for sealing chamber control

Measure the resistor of the electrode with an ohmmeter. The measured value must approach "infinity". For values ≤ 30 kOhm, if there is water in the oil – change the oil!

6.5.3 Connection of the single-phase current motor




Fig. 4: Connection diagram single-phase current motor

6.5.4 Three-phase current motor connection




Fig. 5: Connection diagram three-phase current motor EMU KS...

Wire colour	Terminal
Black (bk)	L
Blue (bu)	N
Green/yellow (gn-ye)	Earth

The single-phase current version is equipped with a shockproof plug. The connection to the mains is established by inserting the plug into a socket. The plug is **not** overflow-proof. **Install the socket so that it is overflow-proof!** Observe the information on the protection class (IP) of the plug.

DANGER! If the pump is connected directly to the switchgear, dismantle the plug and arrange for the electrical connection to be carried out by a qualified electrician!

EMU KS...

Wire colour	Designation	Terminal
Brown (bn)	U	L1
Black (bk)	V	L2
Grey (gy)	W	L3
Green/yellow (gn-ye)	Earth	PE

For three-phase current motors, a clockwise rotating field must be available. The three-phase current version is equipped with a CEE plug or with a bare cable end:

- If a CEE plug is supplied, connection to the mains is established by inserting the plug into a socket. The plug is **not** overflow-proof. **Install the socket so that it is overflow-proof!** Observe the information on the protection class (IP) of the plug.
- If there is a bare cable-end, the pump must be connected directly to the switchgear. **DANGER! If the pump is connected directly to the switchgear, arrange for the electrical connection to be carried out by a qualified electrician!**




Fig. 6: Connection diagram three-phase current motor EMU KS...Ex

6.5.5 Monitoring equipment connection

EMU KS...Ex

Wire	Designation	Terminal
1, 2	20, 21	Monitoring of motor winding
3	U	L1
4	V	L2
5	W	L3
6	DK	Monitoring of motor compartment
Green/yellow (gn-ye)	PE	Earth

The three-phase current version is equipped with bare cable ends. Connection to the mains is established by connecting the power supply cable in the switchgear. **Electrical connection must always be carried out by a qualified electrician!**

For the correct direction of rotation, a clockwise rotating field must be available.

NOTICE! The individual wires are designated according to the connection diagram. Do not cut the wires! There is no additional assignment between the wiring diagram and connection diagram.

Refer to the enclosed connection diagram for details regarding the connection and installation of the monitoring devices. **Electrical connection must always be carried out by a qualified electrician!**

NOTICE! The individual wires are designated according to the connection diagram. Do not cut the wires! There is no additional assignment between the wiring diagram and connection diagram.



DANGER

Risk of explosion due to incorrect connection!

If the monitoring devices are not connected correctly, there is a risk of fatal injury due to explosion in potentially explosive areas! Connection must always be carried out by a qualified electrician. If used in potentially explosive areas:

- Connect the thermal motor monitoring via an evaluation relay!
- Deactivation by the temperature limiter must be conducted with reactivation lock! It must only be possible to restart the unit when the unlock key has been actuated by hand!
- Connect the external electrode (e.g. sealing chamber control) via an evaluation relay with an intrinsically safe circuit!
- Note the additional information in the chapter on potentially explosive areas found in the appendix of these installation and operating instructions!

Overview of monitoring devices:

	KS...	KS...Ex
Motor compartment	-	•
Motor winding	-	•
Motor bearings	-	-
Sealing chamber		
Internal electrode	-	-
External electrode	o	o

Key: - = not available/possible, o = optional, • = as standard

All the monitoring devices fitted must always be connected!

6.5.5.1 Monitoring of motor winding (KS...Ex only)

With bimetallic strip

Connect the bimetallic strips in the switchgear itself or via an evaluation relay.
Connection values: max. 250 V(AC), 2.5 A, $\cos \varphi = 1$

Wiring diagram for bimetallic strip

Temperature limiter

20	Bimetallic strip connection
----	-----------------------------

21

Temperature control

21	High temperature connection
----	-----------------------------

20	Centre terminal
----	-----------------

22	Low temperature connection
----	----------------------------

With PTC sensor

Connect the PTC sensor via an evaluation relay. Relay "CM-MSS" is recommended for this. The threshold is preset.

PTC sensor wiring diagram

Temperature limiter

10	PTC sensor connection
----	-----------------------

11

Temperature control

11	High temperature connection
----	-----------------------------

10	Centre terminal
----	-----------------

12	Low temperature connection
----	----------------------------

Triggering status with temperature control and limiting

Depending on the version of the thermal motor monitoring, the following triggering status must occur when the threshold value is reached:

→ Temperature limiting (1 temperature circuit):

When the threshold is reached, deactivation must take place.

→ Temperature control (2 temperature circuits):

When the threshold for the low temperature is reached, the motor can deactivate with automatic reactivation. When the threshold for the high temperature limit is reached, the motor must deactivate with manual reactivation.

Note the additional information in the chapter on potentially explosive areas found in the appendix!

6.5.5.2 Sealing chamber monitoring (external electrode)

Connect the external electrode via an evaluation relay. Relay "NIV 101/A" is recommended for this. The threshold is 30 kOhm.

When the threshold is reached, a warning must be given or the unit must be switched off.

CAUTION

Connection of the sealing chamber control

If on reaching the threshold, there is only a warning, the pump could be irreparably damaged by the water ingress. Deactivation of the pump is always recommended!

Note the additional information in the chapter on potentially explosive areas found in the appendix!

6.5.6 Motor protection adjustment

Motor protection must be set depending on the selected activation type.

6.5.6.1 Direct activation

At full load, set the motor protection switch to the rated current (see rating plate). At partial load, it is recommended to set the motor protection switch 5 % above the current measured at the duty point.

6.5.7 Operation with frequency converter

Operation on the frequency converter is not permitted.

7 Commissioning



WARNING

Foot injuries due to a lack of protective equipment!

Danger of (serious) injuries during work. Wear safety shoes!

7.1 Personnel qualifications

- Electrical work: A qualified electrician must carry out the electrical work.
- Operation/control: Operating personnel must be instructed in the functioning of the complete system.

7.2 Operator responsibilities

- Providing installation and operating instructions by the pump or at a place specially reserved for it.
- Making the installation and operating instructions available in the language of the personnel.
- Making sure that the installation and operating instructions are read and understood by all personnel.
- All safety devices and emergency cut-outs on the system-side must be active and checked to ensure that they work properly.
- The pump is suitable for use under the specified operating conditions.

7.3 Direction of rotation check (for three-phase current motors only)

The pump is factory-checked and adjusted to the correct direction of rotation for a clockwise rotating field. Connection is made in accordance with the specifications in chapter "Electrical connection".

Direction of rotation check

A qualified electrician checks the rotating field at the mains connection with a rotating field-test device. For the correct direction of rotation, a clockwise rotating field must be available at the mains connection. The pump is **not** approved for operation with a counter-clockwise rotating field! **CAUTION! If the direction of rotation is checked with a test run, comply with the ambient and operating conditions!**

Incorrect direction of rotation

If the direction of rotation is false, change the connection as follows:

- Swap two phases for motors with direct starting.
- Swap the connections of two windings (e.g. U1/V1 and U2/V2) for star-delta activation motors.

Pumps with CEE plug and phase inverter

1. Insert CEE plug into the socket.
 2. Check the control lamp.
 - ⇒ Control lamp off: Direction of rotation ok.
 - ⇒ Control lamp on: Incorrect direction of rotation.
 3. Correct the direction of rotation.
 - ⇒ Use a suitable screwdriver to press in the phase inverter in the plug and turn by 180°.
- Direction of rotation set correctly.




Fig. 7: Phase inverter

7.4 Operation in an explosive atmosphere



DANGER

Risk of explosion due to flying sparks in the hydraulics!

During operation the hydraulics must be flooded (completely filled with the fluid). If the volume flow is interrupted or the hydraulics emerges, air cushions can form in the hydraulics. If this happens, there is a risk of explosion, e.g. flying sparks due to static charge! Dry-running protection must ensure that the pump is deactivated at the appropriate level.

Type	Approval according to		
	ATEX	FM	CSA
KS 5 Ex	•	•	–
KS 6 Ex	•	•	–
KS 8	–	–	–
KS 9	–	–	–
KS 12	–	–	–
KS 14	–	–	–
KS 15	–	–	–
KS 16 Ex	•	•	–
KS 20	–	–	–
KS 24	–	–	–
KS 37	–	–	–
KS 70	–	–	–

Key: – = not available/possible, • = as standard

For use in explosive atmospheres, the pump must be marked as follows on the rating plate:

- “Ex” symbol of the corresponding approval
- Ex classification

For the relevant requirements, refer to the explosion protection chapter in the appendix of these installation and operating instructions!

ATEX approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to group II, category 2. The pumps can be used in both zone 1 and zone 2.

These pumps must not be used in zone 0!

FM approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to the protection class “Explosion proof, Class 1, Division 1”. Therefore, operation in areas with the required protection class “Explosion proof, Class 1, Division 2” is also possible.

7.5 Before switching on

Check the following prior to activation:

- Check whether the device has been installed properly and in accordance with the locally applicable regulations:
 - Has the pump been earthed?
 - Power supply cable routing tested?
 - Electrical connection made according to the regulations?
 - Mechanical components attached correctly?
- Check level control:
 - Float switches can move freely?
 - Switching level tested (pump on, pump off, minimum water level)?
 - Additional dry-running protection installed?
- Test operating conditions:

- Min./max. temperature of the fluid tested?
- Max. immersion depth tested?
- Operating mode defined depending on the minimum water level?
- Maximum switching frequency adhered to?
- Check installation location/operating space:
 - Pipe system on the pressure side free of deposits?
 - Inlet or pump sump cleaned or free of deposits?
 - All gate valves open?

7.6 Switching on and off

During the start process, the rated current is temporarily exceeded. During operation, the rated current may no longer be exceeded. **CAUTION! If the pump does not start, switch off the pump immediately. Remove the fault before reactivating the pump!**

Pumps with bare cable end

The pump must be switched on and off using a separate operating point (on/off switch, switchgear) provided by the customer.

Pump with attached plug

→ After inserting the plug into the socket, the pump is ready for operation. The pump is switched on and off with the ON/OFF switch.

Pump with attached float switch and plug

→ After inserting the plug into the socket, the pump is ready for operation. The pump is controlled via two switches on the plug:

- HAND/AUTO: Determines if the pump is switched on and off directly (HAND) or depending on the fill level (AUTO).
- ON/OFF: Switches the pump on and off.

7.7 During operation



WARNING

Amputation of limbs due to rotating components!

No persons must be present in the work area of the pump! There is risk of (serious) injuries due to rotating components! No persons must be present in the work area of the pump during start-up or operation.



WARNING

Risk of burns from hot surfaces!

Motor housing can become hot during operation. It may cause burns. Allow the pump to cool down at ambient temperature after switching it off!

When operating the pump, observe the locally applicable regulations on the following topics:

- Work safety
- Accident prevention
- Handling electrical machines

Strictly adhere to the responsibilities of the personnel specified by the operator. All personnel are responsible for ensuring that the responsibilities of the personnel and the regulations are observed!

Due to their design, centrifugal pumps have rotating parts that are easily accessible. Depending on the operating condition, sharp edges can develop on these parts. **WARNING! This can lead to cuts and limbs may be severed!** Check the following at regular intervals:

- Operating voltage (+/-10 % of the rated voltage)
- Frequency (+/-2 % of the rated frequency)
- Power consumption between individual phases (max. 5 %)
- Voltage difference between the individual phases (max. 1 %)
- Max. switching frequency
- Minimum water submersion depending on the operating mode
- Inlet: no air intake
- Level control device/dry-running protection: Switching points
- Quiet/low-vibration running

→ All gate valves open

8 Shut-down/dismantling

8.1 Personnel qualifications

- Operation/control: Operating personnel must be instructed in the functioning of the complete system.
- Electrical work: A qualified electrician must carry out the electrical work.
- Installation/dismantling: The technician must be trained in the use of the necessary tools and fixation materials for the relevant construction site.

8.2 Operator responsibilities

- Locally applicable accident prevention and safety regulations of trade associations.
- Observe regulations for working with heavy loads and under suspended loads.
- Provide the necessary protective equipment and make sure that the personnel wears it.
- Provide adequate aeration in closed rooms.
- Take immediate countermeasures if there is a build-up of toxic or suffocating gases!

8.3 Shut-down

The pump is deactivated during decommissioning, but remains installed. This ensures that the pump is always ready for operation.

- ✓ To protect the pump from frost and ice, always immerse the pump completely in the fluid.
- ✓ The temperature of the fluid must always be above +3 °C (+37 °F).
 1. Switch off the pump at the operating point.
 2. Secure the operating point against being switched on again by unauthorised persons (e.g. lock main switch).
- The pump is out of operation and can now be dismantled.

If the pump remains installed after decommissioning, observe the following:

- Ensure that the prerequisites for decommissioning are maintained for the complete period of decommissioning. If these prerequisites cannot be guaranteed, dismantle the pump after decommissioning!
- For an extended period of decommissioning, carry out a 5-minute function test at regular intervals (monthly to quarterly). **CAUTION! A function test may only be carried out under the applicable operating conditions. A dry run is not permitted! Non-compliance can result in irreparable damage!**

8.4 Removal



DANGER

Danger due to fluids hazardous to health!

If the pump is used in fluids hazardous to health, decontaminate the pump after dismantling and before carrying out any other work! There is a risk of fatal injury! Observe the specifications in the work regulations! The operator must make sure that the personnel have received and read the work regulations!



DANGER

Risk of death due to electrocution!

Improper conduct when carrying out electrical work can lead to death due to electric shock! Electrical work must be carried out by a qualified electrician in accordance with the locally applicable regulations.



DANGER

Risk of fatal injury due to dangerous lone working practices!

Work in chambers and narrow rooms as well as work involving risk of falling are dangerous work. Such work may not be carried out autonomously! A second person must be present for safety reasons.

**WARNING****Risk of burns from hot surfaces!**

Motor housing can become hot during operation. It may cause burns. Allow the pump to cool down at ambient temperature after switching it off!

NOTICE**Only use lifting equipment in a technically sound condition!**

Only use lifting equipment in a technically sound condition for lifting, lowering and transporting the pump. Ensure that the pump does not become jammed during lifting and lowering. Do **not** exceed the max. permissible bearing capacity of the lifting equipment!

8.4.1 Portable wet well installation

- ✓ Pump is taken out of operation.
 1. Disconnect the pump from the mains.
 2. Roll up the power supply cable and place it over the motor housing. **CAUTION! Never pull on the power supply cable! This damages the power supply cable!**
 3. Loosen the pressure pipe from the pressure port.
 4. Attach the lifting equipment to the attachment point.
 5. Lift the pump from the operating space. **CAUTION! The power supply cable may be squeezed and damaged when setting the pump down! Pay attention to the power supply cable when setting the pump down!**
 6. Clean the pump thoroughly (see point "Cleaning and disinfecting"). **DANGER! Disinfect the pump when used in fluids hazardous to health!**

8.4.2 Clean and disinfect**DANGER****Danger due to fluids hazardous to health!**

Danger to life if the pump is used in fluids hazardous to health! Decontaminate the pump before carrying out any further work! Wear the following protective equipment while performing cleaning tasks:

- Closed safety goggles
- Breathing mask
- Protective gloves

⇒ The equipment listed here is the minimum requirement, observe the specifications of the work regulations! The operator must make sure that the personnel have received and read the work regulations!

- ✓ Pump is dismantled.
- ✓ The contaminated cleaning water is disposed of in the sewage in accordance with the locally applicable regulations.
- ✓ A disinfectant is provided for contaminated pumps.
 1. Attach the lifting equipment to the attachment point of the pump.
 2. Lift the pump approximately 30 cm above the ground.
 3. Spray the pump with clear water from top to bottom. **NOTICE! An appropriate disinfectant must be used for contaminated pumps! Strictly observe the manufacturer's specifications concerning use!**
 4. To clean the impeller and the interior pump space, guide the water jet inside via the pressure port.
 5. Flush all dirt residue onto the floor of the channel.
 6. Allow the pump to dry out.

9 Maintenance and repair



DANGER

Danger due to fluids hazardous to health!

If the pump is used in fluids hazardous to health, decontaminate the pump after dismantling and before carrying out any other work! There is a risk of fatal injury! Observe the specifications in the work regulations! The operator must make sure that the personnel have received and read the work regulations!

NOTICE

Only use lifting equipment in a technically sound condition!

Only use lifting equipment in a technically sound condition for lifting, lowering and transporting the pump. Ensure that the pump does not become jammed during lifting and lowering. Do **not** exceed the max. permissible bearing capacity of the lifting equipment!

- Always carry out maintenance tasks in a clean location with good lighting. It must be possible to position the pump safely and secure it.
- Only carry out maintenance tasks mentioned in these installation and operating instructions.
- Wear the following protective equipment while performing maintenance tasks:
 - Safety goggles
 - Safety shoes
 - Safety gloves

9.1 Personnel qualifications

- Electrical work: A qualified electrician must carry out the electrical work.
- Maintenance tasks: The technician must be familiar with the use of operating fluids and their disposal. In addition, the technician must have basic knowledge of mechanical engineering.

9.2 Operator responsibilities

- Provide the necessary protective equipment and make sure that the personnel wears it.
- Collect operating fluids in suitable tanks and dispose of properly.
- Dispose of protective clothing used in accordance with regulations.
- Use only original parts of the manufacturer. Use of parts other than the original parts releases the manufacturer from any liability.
- Collect any leakage of fluid and operating fluid immediately and dispose of it according to the locally applicable guidelines.
- Provide the tools required.
- If flammable solvents and cleaning agents are used, open flames, naked lights and smoking are prohibited.

9.3 Operating fluid

9.3.1 Oil types

Biological white oil is added to the motor and the sealing chamber. The following oil types are recommended when changing the oil:

- Aral Autin PL*
- Shell ONDINA 919
- Esso MARCOL 52* or 82*
- BP WHITEMORE WOM 14*
- Texaco Pharmaceutical 30* or 40*

All oil types marked with “*” are approved for use with foods in accordance with “USDA-H1”.

9.3.2 Filling quantities

Type	Sealing chamber	Motor
KS 8, KS 9, KS 14	200 ml (6.8 US.fl.oz.)	900 ml (30.4 US.fl.oz.)
KS 12, KS 15	140 ml (4.7 US.fl.oz.)	820 ml (27.7 US.fl.oz.)
KS 20	400 ml (13.5 US.fl.oz.)	1300 ml (44 US.fl.oz.)
KS 24	350 ml (11.8 US.fl.oz.)	1350 ml (45.6 US.fl.oz.)
KS 37, KS 70	1400 ml (47.3 US.fl.oz.)	3000 ml (101.4 US.fl.oz.)

Type	Sealing chamber	Motor
KS...Ex	550 ml (18.6 US.fl.oz.)	–

9.4 Maintenance intervals

To ensure reliable operation, maintenance tasks must be carried out regularly. Depending on the real ambient temperatures, maintenance intervals different from those mentioned in the contract can be defined! If strong vibrations occur during operation, the pump and the installation must be checked regardless of the defined maintenance intervals.

9.4.1 Maintenance intervals for normal conditions

2 years

- Visual inspection of the power supply cable
- Visual inspection of accessories
- Visual inspection of the coating and housing for wear
- Function test of monitoring devices
- Oil change

NOTICE! If a sealing chamber control is installed, the oil is changed according to the indicator!

15000 operating hours or after 10 years at the latest

- General overhaul

9.4.2 Maintenance intervals for harsh conditions

Under harsh operating conditions, specified maintenance intervals must be shortened if required. Harsh operating conditions include:

- Fluids with long-fibre components
- Turbulent inlet (e.g. due to air intake, cavitation)
- Strongly corroding or abrasive fluids
- Heavily gas generating fluids
- Operation at an unfavourable duty point
- Pressure surges

When using pumps under hard conditions, it is recommended to sign a maintenance contract. Contact customer service.

9.5 Maintenance measures



WARNING

Sharp edges on the impeller and suction port!

Sharp edges can form on the impeller and suction port. There is danger of limbs being severed! Protective gloves must be worn to protect from cuts.



WARNING

Hand, foot or eye injuries due to the absence of protective equipment!

Danger of (serious) injuries during work. Wear the following protective equipment:

- Safety gloves for protection against cuts
- Safety shoes
- Closed safety goggles

The following pre-requisites must be fulfilled prior to starting maintenance measures:

- Pump cooled down to the ambient temperature.
- Pump cleaned thoroughly and disinfected (if required).

9.5.1 Visual inspection of the power supply cable

The power supply cables must be checked for:

- Bubbles
- Cracks
- Scratches
- Abrasion
- Crushing

If the power supply cables are damaged, the pump must be decommissioned immediately! Customer service must replace the damaged power supply cable. The pump may only be started up again once the damage has been properly remedied.

CAUTION! Water may penetrate into the pump due to the damaged power supply cables! Water ingress leads to total damage of the pump.

9.5.2 Visual inspection of accessories

Accessories must be checked for:

- Correct fixation
- Smooth function
- Wear symptoms

Any defects detected must be repaired immediately or the accessories must be replaced.

9.5.3 Visual inspection of coatings and housing for wear

The coatings and housing parts must not show any signs of damage. If there are defects, the following must be observed:

- If the coating is damaged, it must be restored.
- Contact customer service if housing parts have worn out!

9.5.4 Function test of the monitoring device

To test resistances, the pump must be cooled down to the ambient temperature!

9.5.4.1 Test the resistor of the internal electrodes for motor compartment monitoring

Measure the resistor of the electrode with an ohmmeter. The measured value must approach "infinity". For values $\leq 30 \text{ k}\Omega$, there is water in the motor compartment. **Contact customer service!**

9.5.4.2 Test the resistor of the temperature sensor

Measure the resistor of the temperature sensors with an ohmmeter. The following measured values must be complied with:

- **Bimetallic strip:** Measured value = $0 \text{ }\Omega$ (passage).
- **PTC sensor** (PTC thermistor): Measured value depends on the number of sensors installed. At PTC sensor has a cold resistance of between 20 and 100 Ω .
 - With **three** sensors in series, the measured value is between 60 und 300 Ω .
 - With **four** sensors in series, the measured value is between 80 und 400 Ω .

9.5.4.3 Testing the resistor of the external electrode for sealing chamber control

Measure the resistor of the electrode with an ohmmeter. The measured value must approach "infinity". For values $\leq 30 \text{ k}\Omega$, if there is water in the oil – change the oil!

9.5.5 Oil change

An oil change is recommended for these pumps after 2 years. Customer service carries out the oil change on-site.

9.5.6 General overhaul

During the general overhaul, the motor bearings, shaft sealings, O-rings and power supply cables are checked for wear and damage. Damaged components are replaced with original parts. This will ensure correct operation.

The general overhaul is performed by the manufacturer or an authorised service centre.

10 Faults, causes and remedies



DANGER

Danger due to fluids hazardous to health!

Danger of death in case of pumps with fluids hazardous to health! Wear the following protective equipment while performing the work:

- Closed safety goggles
- Breathing mask
- Protective gloves

⇒ The equipment listed here is the minimum requirement, observe the specifications of the work regulations! The operator must make sure that the personnel have received and read the work regulations!

**DANGER****Risk of death due to electrocution!**

Improper conduct when carrying out electrical work can lead to death due to electric shock! Electrical work must be carried out by a qualified electrician in accordance with the locally applicable regulations.

**DANGER****Risk of fatal injury due to dangerous lone working practices!**

Work in chambers and narrow rooms as well as work involving risk of falling are dangerous work. Such work may not be carried out autonomously! A second person must be present for safety reasons.

**WARNING****No persons are allowed to be present inside the working area of the pump!**

Persons may suffer (serious) injuries while the pump is in operation! No persons may therefore be present inside the working area. If persons must enter the working area of the pump, the pump must be decommissioned and secured against being switched on again without authorisation.

**WARNING****Sharp edges on the impeller and suction port!**

Sharp edges can form on the impeller and suction port. There is danger of limbs being severed! Protective gloves must be worn to protect from cuts.

Fault: Pump does not start

1. Electricity supply interrupted or short-circuit/earth fault in the cable or motor winding.
 - ⇒ Have the connection and motor checked by a qualified electrician and replace if necessary.
2. Tripping of fuses, of the motor protection switch or the monitoring device
 - ⇒ Have the connection and the monitoring device checked by a qualified electrician and change it if necessary.
 - ⇒ Have the motor protection switches and fuses installed and adjusted according to the technical specifications by a qualified electrician and reset monitoring device.
 - ⇒ Check the impeller to make sure that it runs smoothly, clean the hydraulics if necessary.
3. The sealing chamber control (optional) has interrupted the electric circuit (connection-related)
 - ⇒ See "Fault: Mechanical seal leakage, sealing chamber control reports a fault and switches the pump off".

Fault: Pump starts up, motor protection trips after short period

1. Motor protection switch set incorrectly.
 - ⇒ Have the adjustment of the trigger checked and corrected by a qualified electrician.
2. Increased power consumption due to major voltage drop.
 - ⇒ Have the voltage of individual phases checked by a qualified electrician. Contact the electricity distribution network.
3. There are only two phases at the connection.
 - ⇒ Have the connection checked and corrected by a qualified electrician.
4. Excessive differences in voltage between the phases.

- ⇒ Have the voltage of individual phases checked by a qualified electrician. Contact the electricity distribution network.
- 5. Incorrect direction of rotation.
 - ⇒ Have the connection corrected by a qualified electrician.
- 6. Increased power consumption through jammed hydraulics.
 - ⇒ Clean the hydraulics and check the inlet.
- 7. The density of the fluid is too high.
 - ⇒ Contact customer service.

Fault: Pump runs, there is no volume flow

1. There is no fluid.
 - ⇒ Check the inlet, open all gate valves.
2. Inlet clogged.
 - ⇒ Check the inlet and remove clogging.
3. Hydraulics jammed.
 - ⇒ Clean the hydraulics.
4. Pipe system on the pressure side or pressure hose clogged.
 - ⇒ Remove clogging and replace the damaged components if necessary.
5. Intermittent operation.
 - ⇒ Check the switching system.

Fault: Pump starts, duty point is not reached

1. Inlet clogged.
 - ⇒ Check the inlet and remove clogging.
2. Slide valves on the pressure side closed.
 - ⇒ Open all gate valves completely.
3. Hydraulics jammed.
 - ⇒ Clean the hydraulics.
4. Incorrect direction of rotation.
 - ⇒ Have the connection corrected by a qualified electrician.
5. Air cushion in the pipe system.
 - ⇒ Vent the pipe system.
 - ⇒ If air cushions occur frequently: Locate and prevent the air intake, if required install ventilation systems at specified locations.
6. Pump pumping against excessive pressure.
 - ⇒ Open all gate valves on the pressure side completely.
 - ⇒ Check the impeller shape, use other impeller shapes if required. Contact customer service.
7. Signs of wear on the hydraulics.
 - ⇒ Have the components (impeller, suction port, pump housing) checked and replaced by customer service.
8. Pipe system on the pressure side or pressure hose clogged.
 - ⇒ Remove clogging and replace the damaged components if necessary.
9. Strongly gassing fluid.
 - ⇒ Contact customer service.
10. There are only two phases at the connection.
 - ⇒ Have the connection checked and corrected by a qualified electrician.
11. Excessive decrease in the fill level during operation.
 - ⇒ Check supply/capacity of the system.
 - ⇒ Have the switching points of the level control checked and adjusted if necessary.

Fault: The pump does not run smoothly and is noisy

1. Improper duty point.
⇒ Check the pump configuration and the duty point, contact customer service.
2. Hydraulics jammed.
⇒ Clean the hydraulics.
3. Strongly gassing fluid.
⇒ Contact customer service.
4. There are only two phases at the connection.
⇒ Have the connection checked and corrected by a qualified electrician.
5. Incorrect direction of rotation.
⇒ Have the connection corrected by a qualified electrician.
6. Signs of wear on the hydraulics.
⇒ Have the components (impeller, suction port, pump housing) checked and replaced by customer service.
7. Motor bearings have worn.
⇒ Inform customer service; send the pump back to the factory for overhauling.
8. Pump is installed under tension.
⇒ Check installation, install rubber compensators if necessary.

Fault: Sealing chamber control reports fault or switches the pump off

1. Condensation water build-up due to extended storage or high temperature fluctuations.
⇒ Operate the pump for a short period (max. 5 min.) without pencil electrode.
2. Increased leakage when running in new mechanical seals.
⇒ Change the oil.
3. Pencil electrode cable is defective.
⇒ Replace the pencil electrode.
4. Mechanical seal is defective.
⇒ Inform customer service.

Further steps for troubleshooting

If the points listed here do not rectify the fault, customer service must be contacted. Customer service can provide the following remedies:

- Telephone or written support.
- On-site support.
- Inspection and repair of the pump at the factory.

Costs may be incurred if other services of the customer service are availed! For more details, please contact customer service.

11 Spare parts

Spare parts are ordered via customer service. To avoid return queries and incorrect orders, the serial or article number must always be supplied. **Subject to change without prior notice!**

12 Disposal
12.1 Oils and lubricants

Operating fluid must be collected in suitable tanks and disposed of in accordance with the locally applicable guidelines.

12.2 Protective clothing

Used protective clothing must be disposed of in accordance with the locally applicable guidelines.

12.3 Information on the collection of used electrical and electronic products

Proper disposal and appropriate recycling of this product prevents damage to the environment and danger to your personal health.



NOTICE

Disposal in domestic waste is forbidden!

In the European Union, this symbol can appear on the product, the packaging or the accompanying documentation. It means that the electrical and electronic products in question must not be disposed of along with domestic waste.

To ensure proper handling, recycling and disposal of the used products in question, please note the following points:

- Only hand over these products at designated, certified collecting points.
- Observe the locally applicable regulations!

Please consult your local municipality, the nearest waste disposal site, or the dealer who sold the product to you for information on proper disposal. Further recycling information can be found at www.wilo-recycling.com.

13 Appendix

13.1 Ex rating

This section contains further information on the operation of the pump in an explosive atmosphere. All personnel must read this section. **This section applies only to Ex-rated pumps!**

13.1.1 Identification of Ex-rated pumps

For use in explosive atmospheres, the pump must be marked as follows on the rating plate:

- “Ex” symbol of the corresponding approval
- Ex classification
- Certification number (depending on the approval)

The certification number, if required by the approval, is printed on the rating plate.

13.1.2 Protection class “Flameproof enclosure” and “Explosion proof”

The motor must be equipped with at least one temperature limiter (1-circuit temperature monitoring). A temperature control (2 circuit temperature monitoring) is also possible.

13.1.3 Intended use



DANGER

Explosion due to pumping of explosive fluids!

Pumping of highly flammable and explosive fluids (gasoline, kerosene, etc.) in pure form is strictly prohibited. There is a risk of fatal injury due to explosion! The pumps are not designed for these fluids.

ATEX approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to group II, category 2. The pumps can be used in both zone 1 and zone 2.

These pumps must not be used in zone 0!

FM approval

The pumps are suitable for operation in potentially explosive areas, which require devices belonging to the protection class “Explosion proof, Class 1, Division 1”. Therefore, operation in areas with the required protection class “Explosion proof, Class 1, Division 2” is also possible.

13.1.4 Electrical connection



DANGER

Risk of death due to electrocution!

Improper conduct when carrying out electrical work can lead to death due to electric shock! Electrical work must be carried out by a qualified electrician in accordance with the locally applicable regulations.

- Always connect the pump to an electrical outlet outside the explosive area. If the connection must be made within the explosive area, then the connection must be carried out in an Ex-rated housing (ignition protection class according to DIN EN 60079-0)! Non-observance may lead to fatal injury due to explosion! Connection must always be carried out by a qualified electrician.
- All monitoring devices outside the “spark-proof areas” must be connected via an intrinsically safe circuit (e.g. Ex-i relay XR-4...).
- The voltage tolerance may not be higher than max. $\pm 10\%$.

Overview of monitoring devices:

	KS...	KS...Ex
Motor compartment	–	•
Motor winding	–	•
Motor bearings	–	–
Sealing chamber		
Internal electrode	–	–
External electrode	o	o

Key: – = not available/possible, o = optional, • = as standard

All the monitoring devices fitted must always be connected!

The connection is made as described in the “Electrical connection” section.

13.1.4.1 Monitoring of motor compartment

13.1.4.2 Monitoring of motor winding



DANGER

Risk of explosion due to overheating of the motor!

If the temperature limiter is connected incorrectly, there is a risk of explosion due to overheating of the motor! Always connect the temperature limiter to a manual re-activation lock. This means that a “release button” must be manually activated!

The motor is equipped with a temperature limiter (1-circuit temperature monitoring).

When the threshold is reached, deactivation must occur with a **restart interlock!**

Connection of the thermal motor monitoring

- Connect the bimetallic strip via an evaluation relay. Relay “CM-MSS” is recommended for this. The threshold is preset.
Connection values: max. 250 V(AC), 2.5 A, $\cos \varphi = 1$
- Connect the PTC sensor via an evaluation relay. Relay “CM-MSS” is recommended for this. The threshold is preset.
- Connect the external pencil electrode via an Ex-rated evaluation relay! Relay “XR-4...” is recommended for this.
The threshold is 30 kOhm.
- The connection must be made using an intrinsically safe circuit!

13.1.4.3 Sealing chamber monitoring (external electrode)

13.1.5 Commissioning



DANGER

Risk of explosion when using non Ex-rated pumps!

Pumps without Ex rating may not be used in potentially explosive areas! There is a risk of fatal injury due to explosion! Only use pumps which have the appropriate Ex labelling on the rating plate within potentially explosive areas.

**DANGER****Risk of explosion due to flying sparks in the hydraulics!**

During operation the hydraulics must be flooded (completely filled with the fluid). If the volume flow is interrupted or the hydraulics emerges, air cushions can form in the hydraulics. If this happens, there is a risk of explosion, e.g. flying sparks due to static charge! Dry-running protection must ensure that the pump is deactivated at the appropriate level.

**DANGER****There is a risk of explosion if dry-running protection is connected incorrectly!**

If the pump is operated within an explosive atmosphere, the dry-running protection must have a separate signal transmitter (redundant protection of the level control). Pump deactivation must be performed with a manual reactivation lock!

- The operator is responsible for defining the potentially explosive area.
- Only pumps with corresponding Ex rating may be used within a potentially explosive area.
- Pumps with Ex rating must be labelled on the rating plate.
- Do not exceed the **maximum fluid temperature!**
- Dry running of the pump must be prevented! Ensure on-site (dry-running protection) that emerging of the hydraulics is prevented.
According to DIN EN 50495, a safety device with SIL level 1 and hardware fault tolerance 0 must be provided for category 2.

13.1.6 Maintenance and repair

- Carry out maintenance tasks according to the regulations.
- Only carry out maintenance tasks mentioned in these installation and operating instructions.
- The spark-proof gaps may **only** be repaired according to the manufacturer's design specifications. It is **not** permitted to carry out repairs according to the values in tables 1 and 2 of DIN EN 60079-1.
- Only use screw plugs as stipulated by the manufacturer, that at least correspond to a strength class of 600 N/mm² (38.85 long tons-force/inch²).

13.1.6.1 Repair of housing coating

The paint layer can become electrostatically charged in case of thicker coats. **DANGER! Risk of explosion! In explosive atmospheres, a discharge can cause an explosion!**

If the housing coating has to be repaired, the maximum coat thickness is 2 mm (0.08 in)!

13.1.6.2 Changing the mechanical seal

Changing the seal on the fluid and motor side is strictly prohibited!

13.1.6.3 Changing the power supply cable

Changing the power supply cable is strictly prohibited!



RENTWAY



RENTWAY

Wilo – International (Subsidiaries)

Argentina

WILO SALMSON
Argentina S.A.
C1295ABI Ciudad
Autónoma de Buenos Aires
T +54 11 4361 5929
matias.monea@wilo.com.ar

Australia

WILO Australia Pty Limited
Murrarrie, Queensland, 4172
T +61 7 3907 6900
chris.dayton@wilo.com.au

Austria

WILO Pumpen Österreich
GmbH
2351 Wiener Neudorf
T +43 507 507-0
office@wilo.at

Azerbaijan

WILO Caspian LLC
1065 Baku
T +994 12 5962372
info@wilo.az

Belarus

WILO Bel IOOO
220035 Minsk
T +375 17 3963446
wilo@wilo.by

Belgium

WILO NV/SA
1083 Ganshoren
T +32 2 4823333
info@wilo.be

Bulgaria

WILO Bulgaria EOOD
1125 Sofia
T +359 2 9701970
info@wilo.bg

Brazil

WILO Comercio e
Importacao Ltda
Jundiaí – São Paulo – Brasil
13.213-105
T +55 11 2923 9456
wilo@wilo-brasil.com.br

Canada

WILO Canada Inc.
Calgary, Alberta T2A 5L7
T +1 403 2769456
info@wilo-canada.com

China

WILO China Ltd.
101300 Beijing
T +86 10 58041888
wiloobj@wilo.com.cn

Croatia

WILO Hrvatska d.o.o.
10430 Samobor
T +38 51 3430914
wilo-hrvatska@wilo.hr

Cuba

WILO SE
Oficina Comercial
Edificio Simona Apto 105
Siboney. La Habana. Cuba
T +53 5 2795135
T +53 7 272 2330
raul.rodriguez@wilo-cuba.com

Czech Republic

WILO CS, s.r.o.
25101 Cestlice
T +420 234 098711
info@wilo.cz

Denmark

WILO Nordic
Drejergangen 9
DK-2690 Karlslunde
T +45 70 253 312
wilo@wilo.dk

Estonia

WILO Eesti OÜ
12618 Tallinn
T +372 6 509780
info@wilo.ee

Finland

WILO Nordic
Tillinmäentie 1 A
FIN-02330 Espoo
T +358 207 401 540
wilo@wilo.fi

France

Wilo Salmson France S.A.S.
53005 Laval Cedex
T +33 2435 95400
info@wilo.fr

United Kingdom

WILO (U.K.) Ltd.
Burton Upon Trent
DE14 2WJ
T +44 1283 523000
sales@wilo.co.uk

Greece

WILO Hellas SA
4569 Anixi (Attika)
T +302 10 6248300
wilo.info@wilo.gr

Hungary

WILO Magyarország Kft
2045 Törökbálint
(Budapest)
T +36 23 889500
wilo@wilo.hu

India

Wilo Mather and Platt Pumps
Private Limited
Pune 411019
T +91 20 27442100
services@matherplatt.com

Indonesia

PT. WILO Pumps Indonesia
Jakarta Timur, 13950
T +62 21 7247676
citrawilo@cbn.net.id

Ireland

WILO Ireland
Limerick
T +353 61 227566
sales@wilo.ie

Italy

WILO Italia s.r.l.
Via Novegro, 1/A20090
Segrate MI
T +39 25538351
wilo.italia@wilo.it

Kazakhstan

WILO Central Asia
050002 Almaty
T +7 727 312 40 10
info@wilo.kz

Korea

WILO Pumps Ltd.
20 Gangseo, Busan
T +82 51 950 8000
wilo@wilo.co.kr

Latvia

WILO Baltic SIA
1019 Riga
T +371 6714-5229
info@wilo.lv

Lebanon

WILO LEBANON SARL
Jdeideh 1202 2030
Lebanon
T +961 1 888910
info@wilo.com.lb

Lithuania

WILO Lietuva UAB
03202 Vilnius
T +370 5 2136495
mail@wilo.lt

Morocco

WILO Maroc SARL
20250 Casablanca
T +212 (0) 5 22 66 09 24
contact@wilo.ma

The Netherlands

WILO Nederland B.V.
1551 NA Westzaan
T +31 88 9456 000
info@wilo.nl

Norway

WILO Nordic
Alf Bjerckes vei 20
NO-0582 Oslo
T +47 22 80 45 70
wilo@wilo.no

Poland

WILO Polska Sp. z o.o.
5-506 Lesznowola
T +48 22 7026161
wilo@wilo.pl

Portugal

Bombas Wilo-Salmson
Sistemas Hidraulicos Lda.
4475-330 Maia
T +351 22 2080350
bombas@wilo.pt

Romania

WILO Romania s.r.l.
077040 Com. Chiajna
Jud. Ilfov
T +40 21 3170164
wilo@wilo.ro

Russia

WILO Rus ooo
123592Moscow
T +7 496 514 6110
wilo@wilo.ru

Saudi Arabia

WILO Middle East KSA
Riyadh 11465
T +966 1 4624430
wshoula@wataniaind.com

Serbia and Montenegro

WILO Beograd d.o.o.
11000 Beograd
T +381 11 2851278
office@wilo.rs

Slovakia

WILO CS s.r.o., org. Zložka
83106 Bratislava
T +421 2 33014511
info@wilo.sk

Slovenia

WILO Adriatic d.o.o.
1000 Ljubljana
T +386 1 5838130
wilo.adriatic@wilo.si

South Africa

Wilo Pumps SA Pty LTD
Sandton
T +27 11 6082780
gavin.bruggen wilo.co.za

Spain

WILO Ibérica S.A.
28806 Alcalá de Henares
(Madrid)
T +34 91 8797100
wilo.iberica@wilo.es

Sweden

WILO NORDIC
Isbjörnsvägen 6
SE-352 45 Växjö
T +46 470 72 76 00
wilo@wilo.se

Switzerland

Wilo Schweiz AG
4310 Rheinfelden
T +41 61 836 80 20
info@wilo.ch

Taiwan

WILO Taiwan CO., Ltd.
24159 New Taipei City
T +886 2 2999 8676
nelson.wu@wilo.com.tw

Turkey

WILO Pompa Sistemleri
San. ve Tic. A.Ş.
34956 İstanbul
T +90 216 2509400
wilo@wilo.com.tr

Ukraine

WILO Ukraine t.o.w.
08130 Kiev
T +38 044 3937384
wilo@wilo.ua

United Arab Emirates

WILO Middle East FZE
Jebel Ali Free zone – South
PO Box 262720 Dubai
T +971 4 880 91 77
info@wilo.ae

USA

WILO USA LLC
Rosemont, IL 60018
T +1 866 945 6872
info@wilo-usa.com

Vietnam

WILO Vietnam Co Ltd.
Ho Chi Minh City, Vietnam
T +84 8 38109975
nkminh@wilo.vn

wilo

RENTWAY

Pioneering for You

WILO SE
Nortkirchenstr. 100
44263 Dortmund
Germany
T +49 (0)231 4102-0
T +49 (0)231 4102-7363
wilo@wilo.com
www.wilo.com