



CAUTION

During work, inspect whether milling rings still freely rotate on axes. If it is not the case, e.g. due to accumulated dust; it is necessary to remove it from the milling head. For this reason the machine should not be operated without suction system connected!

8.1 Suction system

To ensure the operability of suction system, put the hose (36 mm diameter) of some Festool brand vacuum cleaner onto the handle adaptor [1-4]. Keep in mind that as filtration sack is being filled, the suction effectiveness significantly reduces. Also clean vacuum cleaner's filter time to time.



CAUTION

Always operate the machine with the suction system connected; otherwise, the milling rings as well as suction flange height adjustment system will be clogged with dust!

To prevent discharges of static electricity in dusty environment, use vacuum cleaners of antistatic models only.

8.2 Additional handle

To operate the grinder with both hands, it is possible to fasten an additional handle [1-1] to the left-hand side of gearbox cover's front part. The special "VIBRASTOP" design reduces vibrations in the additional handle.

9 Service and maintenance



WARNING

Risk of accident, electric shock

- ▶ Always pull the plug out of the socket before performing any type of work on the machine.
- ▶ All maintenance and repair work which requires the motor housing to be opened, must only be carried out by an authorised service workshop.

- Wrapped electric tools can be stored in a dry place without heating, with temperatures not lower than -5°C. Unwrapped electric tools can only be stored in dry places with temperatures not lower than +5°C, without sudden changes in the temperature.

- To ensure the airflow is sufficient, cooling openings of the motor must be always clean and free.
- The machine is equipped with special self-disconnecting brushes. When the brushes are worn, the power supply is automatically disconnected, and the machine is stopped.
- If the suction flange height adjustment system does not operate smoothly, the flange must be removed and cleaned.



Customer service and repair. Only through manufacturer or service workshops: Please find the nearest address at: www.festool.net/service



Use only original Festool spare parts! Order No. at: www.festool.net/service

10 Environment

Do not throw the power tool in your household waste! Dispose of the machine, accessories and packaging at an environmentally-responsible recycling centre! Observe the valid national regulations.
EU only: European Directive 2002/96/EC stipulate that used electric power tools must be collected separately and disposed of at an environmentally responsible recycling centre.

Information on REACH:

www.festool.com/reach

11 EU Declaration of Conformity

Renovation Cutter	Serial no.
RG 80 E	769231, 768829, 768798

Year of CE mark: 2013

We declare under sole responsibility that this product comply with all relevant requirements of the following directives, norms or normative documents:

2006/42/EC, 2004/108/EC, 2011/65/EU, EN 55 014-1, EN 55 014-2, EN 60 745-1, EN 60 745-2-3, EN 61 000-3-2, EN 61 000-3-3.

Festool Group GmbH & Co. KG

Wertstr. 20, D-73240 Wendlingen

ppa. Dr. Martin Zimmer

Dr. Martin Zimmer
Head of Research, Development and Technical Documentation
2013-04-15